

User Manual

C-MOR Video Surveillance V 5.x

Manual-Version 5.21



General instructions for configuration and operation of the models:

Hardwareserver/A	ppliances		Virtual Machine - Softwareinstallations
C-MOR 3S Pro/SSD	C-MOR15 TPro/SSD	C-MOR 15RM Pro/SSD	C-MOR3 V5 VirtualMachine
C-MOR 3Pro/SSD			C-MOR6 V5 VirtualMachine
C-MOR 6Pro/SSD			C-MOR9 V5 VirtualMachine
C-MOR 9Pro/SSD			C-MOR12 V5 VirtualMachine
			C-MOR15 V5 VirtualMachine

https://www.c-mor.com

© 2020 by za-internet GmbH

Introduction

Dear customer,

Thank you for choosing the C-MOR video server. The quality product you have purchased is state-of-theart and complies with European and national directives. The declaration of compliance has been confirmed and all necessary documents are deposited with the manufacturer.

To ensure the best results and long-term satisfaction and to ensure safe operation, the instructions in this manual must be followed. In case of questions, please contact your specialist dealer.

The video server C-MOR is used for the surveillance of objects. The video signals recorded during surveillance are digitally transferred over the connected network from your camera to C-MOR. The software installed on the hardware enables simultaneous recordings of max. 15 connected video signals. Data saving underlies country-specific guidelines. You are able to access installed cameras and servers (secured by password and encryption) over your web browser from all over the world.

In case of technical problems or questions on installation and setup of C-MOR, please contact our hotline. Please find more information on www.c-mor.us (or please see contact data in the appendix of this manual).

Before putting into operation

The use of surveillance systems may be prohibited or regulated by law in certain countries. C-MOR has not only been developed for high performance use over the internet, but can also be part of a flexible surveillance facility.

Before putting the system into operation, the user has to make sure that surveillance is carried out within regulatory framework. Before installation, please make sure that the package content is complete. In order to avoid damage by incorrect connection or wrong configuration, please read the manual carefully before using this device, follow the instructions and keep the manual for future use. Following the instructions ensures that the device will be correctly put into operation. Please visit our forum for solutions on www.c-mor.com for FAQ on configuration errors. In case you encounter problems during the setup of your system, please visit the forum as a first step for finding a solution.



Table of Contents

1		ion	
		t	
		mer	
_		nera Quick Installation	
2		b Interface	
		age	
		a Page	
		Start Page	
		lings	
		Recordings	
		Recordings	
		ecordings	
		Recordings	
		n Administration	
		m Status	
		CPU Load	
	2.10.2	Camera availability and the Network Utilization	
	2.10.3	System Log File	
	2.11 Contr	ol with the iPad	
	2.11.1	The Web Interface of the iPad	. 32
	2.11.2	Quickstart	
	2.11.3	Camera selection and live-view	. 34
		e Devices	
	2.12.1		
	2.12.2	Display of Live Images on the iPhone	
3		tration	
		n Administration	
	3.1.1	System Name	
	3.1.2	Change IP Settings	
	3.1.3	Generating and Installation of SSL-Certificates	
	3.1.4	Proxy-Server Configuration	
	3.1.5	Email Alarm Configuration	
	3.1.6	Set Time	
	3.1.7	Configuration of Time Zone	
	3.1.8	Time Server Configuration.	
	3.1.9	Maintenance Mode, activation and deactivation of Recordings	
	3.1.10	Storage Time of Recordings	
	3.1.11	Automated Deletion of oldest Recordings	
	3.1.12	Change Camera Configuration	
	3.1.13	User Administration	
	3.1.14	Access Control according to the two man rule	
	3.1.15	Setup User Settings and Permissions	
	3.1.16	FTP Server Configuration	.67
	3.1.17	SFTP Server Configuration	
	3.1.18	Language	
	3.1.19	Start Page Configuration	
	3.1.20	Remote Access	
ი	3.1.21 1.21.3 St	Stacking function - interconnecting several C-MOR units*	
ა.	3.1.22	acking Live View function	
	3.1.22	System Restart.	
	3.1.23	System Shutdown Software- and Camera Updates	
	3.1.24	License Upgrade	
	J. I.ZJ	License opyraue	. 03



	3.1.26	Backups	
	3.1.27	Stream-Type	
	3.2 Camer	a Configuration	
	3.2.1	General Description of Configuration Options	
	3.2.2	Camera Activation	
	3.2.3	Camera Configuration, Integration of Existing Camera	
	3.2.4	Camera Type	
	3.2.5	Manual configuration of a camera	
	3.2.6	Protocol	
	3.2.7	E-Mail-Alarm by Motion-Detection	
	3.2.8	Image Mask for the Definition of the Areas for Motion Detection	
	3.2.9	The C-MOR PTZ Control	
	3.2.10	Usage of the PTZ control	
4	Legal In	formation	
		mer	
	4.2 Warrar	ıty	
5	GNU Pu	ublic License, GPL	
	5.1 Pream	ole	
		and Conditions for Copying, Distribution and Modification	
6	Append	ix - Contact Information	



1 Installation

This user manual is a general documentation for all C-MOR models. Those models are all hardware versions as well as all virtual machine versions. For each version exists an extra installation guide which is online available on the C-MOR home page <u>https://www.c-mor.com</u>. Download the installation guide from the C-MOR web to learn more how to do the initial set up of C-MOR. The installation process is described in this manual.

Following C-MOR models are available

- Compact server case for 3 to 9 cameras in the basic configuration
- Rack mount Server for computer centers or 19 inch rack mount shelves for 9 to 15 cameras
- Low power consuming and fan less mini case for 3 cameras in the basic configuration
- Tower Server for 15 Cameras
- Software server for the installation on a virtual server or in a cloud.

1.1 Support

In case of unexpected problems during the C-MOR installation please contact our support by the help of the online support-form under <u>https://www.c-mor.com</u>. Please contact your dealer where you bought C-MOR first if you have any questions.

Please also check out the support forum on our homepage where you can find many cases that might answer your questions.

Note

Our technicians will be pleased to help you with remote maintenance, but please note that the corresponding support are subject to a charge. The prices and conditions can be found on our website.



1.2 Disclaimer

When you first call the C-MOR web interface, you are prompted to read and accept the Disclaimer. Without this, it is not possible to use the C-MOR!

Disclaimer

 Unitation of Galaxy, NUTWITHSTANDING ANYTHING ELSE: INTHIS AGREEMENT OR UTHERINASE, 0.4008 (ML), H NO.
EVENT DE DADIE MITH RESPECT TO MAY SUBJECT INVITES UNDER ANY CONTRACT DESUBERIES, STRUT UNBUTYOR
OTHER LEGAL, DONTRACTLAL OR EQUIDABLE THEORY FOR (ILANY INDIRECT, SPECIAL INCODENTIAL INCOME EQUENTIAL)
CAMAGES, NOMEVER GAUSED AND REFERENCE NOT ADVICED IN ADVANCE OF THE POSSEDLEY OF SUCH GAUARES.
OR IN DRANGES FOR LINET PORTED IN THE LINE WAR OF INT PORT OF PORTUGENESS OF SUBSTITUTE GROUP.
TO INCOME INSERVICES, NO WITH SAVING ANY TIMES IN THE ACCEPTING TO THE DOUGHING A THE FALLINE OF
ESSENTIAL PLANOSE OF ANY UMBILITION OF LABULTY OR IMPED REVERT CHORES ENTINE AGARDANE (ADULTY
ABSNUTCEM OF BUILDING TO THE ASSETSED OF THE SUBJECT BALLER HEREOF UNITED BY UPDAT
VIET HES IN LONDING 1. TOWN HORMARY OF IT HESPISE, SHALL OF LIMITED TO THE AMOUNTS RECEIVED OF LIMIN
UNITED THIS ASSETSATES IT WITH RESPECT TO THE PARTICULAR TRANSACTION CARRS ROLE TO THE QUAR RECORDS BY
NOW IF THE PARLE PARCIES RESELTED FOR EACH NONTH GUEN APPLICABLE END IDED ING ING THE PARCHICE

3: CROR does not wanted that the use or operation of this product will be employed, not does it wanted that any data shared on the product will remain account the product will be any fixed operation. Second your data-frequently to multiple types of storage media.


Accept Disclaimer	Decline Disclaimer
-------------------	--------------------

1.3 IP Camera Quick Installation

If C-MOR is installed and you have access to the network, the following steps will show you, how to take an IP-camera without special settings via C-MOR in operation.

C-MOR video surveillance is configured by web interface only. All settings are made through the web management surface.

Log in to your C-MOR video surveillance system. Simply enter the IP address of the C-MOR in your web browser window. The default IP address is 192.168.1.2. Please enter <u>https://192.168.1.2</u> if you have not changed the IP address. The default login is **"admin**" and the default password is also **"admin**".



Please select the "System Administration" menu on top of the C-MOR web page to setup your IP camera.




	IP Video	Surveill	ance	Motion Detection is on Email Alarm is on	C-MOR-Stream			
O-MOR	V5.21 admin	Disk Usage: 4	%					
C-IVIS	Start	Menu		Quickstart	Recordings	System Administration	System Status	Logout
and you see more!	Cam 1	Cam 2	Cam 3					

Scroll down to the section where you can configure IP cameras and select for example the first IP camera, cam1:

Camera Configuration	(open/close)
Change Configuration Camera 1	
Change Configuration Camera 2	
Change Configuration Camera 3	

Alternatively, you can access the camera configuration directly via the camera side "Camera 1".



Once you are in the IP camera configuration menu of camera one, you simply enter the IP address of the camera, the access data, username and password, as well as the TCP/IP Port. This is mostly port number 80 for HTTP camera streams or 554 for RTSP camera streams:



Camera Network Data

Comoro Notwork Data

IP Address/DNS Name	172.20.1.68
TCP-IP-Port	554
User Name	viewer
Password	

Once you have entered the IP data of the camera you can use the button "Check IP and Port" if the camera is reachable by C-MOR:

IP Address/DNS Name	172.20.1.68
TCP-IP-Port	554
User Name	viewer
Password	
Check IP and Port	
OK! The camera can be r	eached in the network: IP: 172.20.1.68, TCP-Port 554

Note

This check only tests the reachability of the camera over network. Login credentials will not be checked!

You can also directly adjust the setting, how long the recordings should be stored:





Now select your IP camera model from the "Camera Type Configuration" menu and press "Save Configuration". In this example a VIVOTEK Camera with the default cam size was selected. At this point all required parameters for the basic motion and time-lapse recordings are made already:

Camera Type Configuration

Please select the cam type that matches the connected cam:

Cam Type	Q Vivotek
	VIVOTEK FD8177-HT RTSP Stream 1 New VIVOTEK FD8179-H MJPEG Stream 1 VIVOTEK FD8179-H MJPEG Stream 1 New VIVOTEK FD8179-H RTSP Stream 1 VIVOTEK FD8179-H RTSP Stream 1 VIVOTEK FD8365EHV MJPG VIVOTEK FD8366-V MJPEG Stream 1 VIVOTEK FD8366-V MJPEG Stream 1 VIVOTEK FD8366-V RTSP Stream 1 VIVOTEK FD8366-V RTSP Stream 1 VIVOTEK FD8366-V RTSP Stream 1 VIVOTEK FD8366-V MJPEG Stream 1 VIVOTEK FD8367A-V MJPEG Stream 1 VIVOTEK FD8367A-V MJPEG Stream 1 VIVOTEK FD8367A-V MJPEG Stream 1
	VIVOTEK FD8367A-V RTSP Stream 1 VIVOTEK FD8367A-V RTSP Stream 1 New VIVOTEK FD8369A-V MJPEG Stream 1
Protocol	rtsp:// 🗘
Manual path	/live.sdp

Click "Save Configuration" after you have set entered the camera network and access values. Motion detection parameters, recording length of videos etc. can be set up later after making sure the camera works in general

On the next page, the saved configuration page, you have to activate your camera by clicking "Start recording".

C-MOR		Disk Usage: 4	%	Motion Detection is on Email Alarm is on	C-MOR-Stream			
C-IVIS	Star	t Menu		Quickstart	Recordings	System Administration	System Status	Logout
and you see more!	Cam 1	Cam 2	Cam 3					
	Saved	Configu	ration fo					
	Recording) cam 1: <mark>dea</mark>	ctivated					

The status shows now, that recording for the IP camera has been activated:

C-MOR	IP Video Surveilla V5.21 admin Disk Usage: 4%		Motion Detection is on Email Alarm is on	C-MOR-Stream			
0-11013	Start Menu		Quickstart	Recordings	System Administration	System Status	Logout
and you see more!	Cam 1 Cam 2	Cam 3					
	Recording for cam 1 ha Stop Recording System Administration Start Page		ctivated.				

If all parameters are set correct, you are able to see the live view of the camera on the start page:



Now it's time to do some testing. Click on the cam1 menu on top and verify when (motion) recordings are generated. From this menu you simply click on "Cam Configuration" to optimize the parameters for motion-detection, alarm emails, with or without attached videos, the length of single recordings and so on. Details on the settings can be found in this manual in the chapter "Administration".



2 The Web Interface

The main tool for the operation and administration of C-MOR is the web interface. Enter the IP address which you have set for example 172.20.1.234. If you don't have changed your IP address insert the default IP address such as 192.168.1.2 into the address bar of your web browser as described under step 2. A window will pop up asking for your user name and password.

The unit is supplied with one pre-configured Administrator user name and password, set to operate and administrate, respectively.

User name: admin, standard password admin

	72.20.1.234:80 requires a username and
password. The serv	ver says: C-MOR Web-Administration.
User Name:	admin
Password:	*****

C-MOR is being controlled by your individual settings over your web browser:

- Time-controlled recordings
- View of live stream by camera
- Sensitivity of motion detection
- User administration: distribution of rights, creation of new user etc.
- · Call, search and display old recordings either as video files or single frames
- Archiving of recordings
- FTP transfer of recordings to a server
- Deletion of recordings for the release of free disk space
- Integration of own/existing cameras (when supported by the system)
- And many more

More information can be found in chapter "Administration".

Besides HTTP connections that are transferred over the Internet without encryption C-MOR also offers encrypted access over HTTPS. In order to use this so-called SSL connection, enter https instead of http in the URL, such as https://c-mor.your-domain.com or https://IP-address (e.g. 192.168.1.2).


Apart from the standard ports 80 for HTTP and port 443 for HTTPS, C-MOR can also be used over the alternative port 9000 (for HTTP) and port 9443 (for HTTPS). These alternative ports are used when C-MOR is accessed over a firewall and the respective ports on the firewall are already in use by other applications.

The web surface is divided into 6 main web pages that are built on each other and individual pages for the corresponding camera:



2.1 Start Page

The start page consists of the menu in the upper section of the page, 6 camera live views and the reference to the camera functions.



On the start page you will find an overview of all functions for the operation and administration of C-MOR. As soon as a camera within the net is activated and starts recording, an up-to-date snapshot by the camera will be displayed. The camera stream size changes with the width of the web browser window. If this is changed the camera streams change the size accordingly.

If you are logged in as admin (administrator) on C-MOR and if you have C-MOR Version 4.01 or newer you will see on the right top two buttons to activate or deactivate the motion detection or email alarm with a single click.




These buttons are also available on mobile devices.



2.2 Camera Page


In example by clicking the button "Cam 1" you will get to the "Camera Page" of camera 1. Here you will be able to see a live image of your camera - provided there is an active connection to it. Furthermore, on this page you have the possibility to play the recordings of the respective camera, to save, to get to the page where the camera can be configured and to view a live stream in a separate window. Also, you can see a preview of each recording. You only have to move your mouse pointer over the preferred video. By clicking on the pictures, you can play the recordings or save them on your local workstation computer.





2.3 Quick Start Page

On the Quick Start page you are able to choose the size of the stream by clicking on the play button of the camera in question. Then the live stream will be opened and start playing in the requested size in a separate window.



The Quick Start Page has a great advantage! It starts up quickly even it is accessed through a slow Internet connection. The small thumb nail camera pictures are updated in a very low refresh rate only. Every few seconds the image will be updated. This means that this page is not usable for live monitoring.

Another advantage of this page is the independent view of single camera streams. Users have the capability to open camera stream by camera stream and place the single views where ever they want to have it on their screen. Also, this single camera live streams are enabling users to use ActiveX cameras in combination with Apple's Safari or other non-Internet Explorer web browsers!

The following site will show you an example of the different sizes of the livestream view.





Livestream in full camera resolution, 768x576 pixels in this example



Fourth camera resolution, 192x144 pixels



2.4 Recordings

Under the menu item "Recordings" your recordings can be administrated. The main functions of this page are selecting recordings by camera and time frame to review or save the recordings, upload to a FTP Server, delete recordings by camera and time frame and single selected deletion of recordings:


OMOR	IP Video Surveilla V5.21 admin Disk Usage: 4%				l	Notion Detection is on Email Alarm is on	C-MOR-Stream
C-MON	Start Menu	Quicksta	t F	Recordings	System Administration	System Status	Logout
and you see more!	Cam 1 Cam 2	Cam 3 Cam 4	Cam 5 Ca	im 6			
You are in the				Rec	cordings Overview		
Recordings Menu							
Selection of Recordings	Recordings Selec	tion for Viewing	or Saving				
Selection of recordings for specific time periods, cams and recording types.		Day: 16 ᅌ Month Day: 16 ᅌ Month					
Admin Mode: FTP-Server Selection of recordings that have to be manually uploaded to the already configured FTP server. The FTP server data are configured in the System Administration.		2 Cam 3					
Admin Mode: Deletion of Recordings	 Recordings by Mo Permanent Record 	tion Detection					
Selection of recordings for manual deletion previous to the automatic deletion by the system.	Display Recordings						
Admin Mode: Deletion of Single Recordings	Save Recordings	to FTP Server					
Recordings of the individual cams will be displayed and can be specified for the deletion of	Start Hour: 0 ᅌ	Day: 16 📀 Monti	n: 09 ᅌ Yes	ar: 2020 ᅌ			
individual sections.	End Hour: 24 ᅌ	Day: 16 ᅌ Month	n: 09 ᅌ Yea	ar: 2020 ᅌ			
	Cam 1 Cam 2	2 Cam 3					
	Cam 4 Cam 5						
	Recordings by Mo						
	Permanent Record						
	Upload Recordings to FT (Saving may take son Please do not cancel	ne minutes.					
	It is only possible to up	load recordings that h	ave been recor	ded more than or	ne hour ago and are no longer involved in a cu	rrent recording.	

In the lower part you find the functions for deleting your recordings.

Delete Recordings		
Start Hour: 0 ᅌ Day: 16	ᅌ Month: 09 ᅌ Year:	2020 ᅌ
End Hour: 24 ᅌ Day: 16	ᅌ Month: 09 ᅌ Year:	2020 ᅌ
Cam 1 Cam 2 Can	3	
Cam 4 Cam 5 Can	6	
Recordings by Motion Detection	ion	
Permanent Recordings		
Delete Recordings		
Delete Single Recordings		
Delete Single Recordings		
Start Hour: 0 ODay: 16	≎ Month: 09 ≎ Year:	2020 📀
	Month: 09	
Start Hour: 0 ODay: 16		
Start Hour: 0 ODay: 16 End Hour: 24 ODay: 16		
Start Hour: 0 © Day: 16 End Hour: 24 © Day: 16 Camera: 0		



Once you have selected the time frame, camera and the recording types the next page shows you all found recordings as motion snapshot preview pictures. Use the mouse-over a picture to see in a little preview video the scene which was recorded in the selection.



The same motion snapshot preview function is in all camera pages available:





Each individual user can set the size of the preview pictures and the preview individually in the user settings. The user settings can be found in the "System Administration" page under "User Administration".


2.5 Show Recordings

By clicking on the button "Display Recordings" on the "**Recordings**" site you have the choice to select separate cameras, a desired period to display and the type of your desired recordings.





After your selection of camera, desired period and type of your recordings (motion detection or permanent recordings) you will be redirected on following site.




On this page you see pictures of your recordings and you have the opportunity to look first to the preview videos. This preview videos show you a few seconds of the complete recording. Just move the cursor over the image.

2.6 Save Recordings

You can play recordings or save them. First you need to select the number of scenes, which is to be stored or played





After clicking on the picture there will be a message for 5 seconds with the following text." Video starts. Please wait! ". After that it appears another window which asks you if you want to save or to open the file. For saving you confirm your selection by clicking on the button "Save".

Ope	ning s20150515-10-timelapse.mp	9
ou have chosen to	open:	
s20150515-1	0-timelapse.mpg	
which is: Mov	vie Clip (103 KB)	
from: http://1		
What should Firefo	ox do with this file?	
O Open with	Windows Media Player (default)	~
 Open with Save File 	Windows Media Player (default)	×
Save File		· ·
Save File		~
Save File		
Save File		

Now you can save space and delete the single recording on C-MOR.

Note

C-MOR tries to control your browser in that way. That always a window appears which is asking you, if you want to save or to watch the film. But if your browser doesn't show you that possibilities, you have to check the settings of your browser. And if you want your browser to ask you, you have to change the settings of your browser.

For every Recording which was recorded by the reason of motion, there are separate single-frame-scenes, in case of you have activated them.





By clicking on "Frames" you will be redirected on the site, where you can look at the single pictures or you can download them as ZIP-file.

If you have a Mac from Apple and your recordings can not be played, you have to go to the menu item "System Administration" and select the respective user:

User Administration Open/c						
User	Display Name		Change Password	User Configuration	Delete User	
admin	Administrator	Change Display Name	Change Password	User Configuration		
demo	Demo User	Change Display Name	Change Password	User Configuration	Delete User	
macdemo	Mac Demo User	Change Display Name	Change Password	User Configuration	Delete User	
vindowspad	Windows Tablet Demo User	Change Display Name	Change Password	User Configuration	Delete User	
michaelr	Michael Reuschling	Change Display Name	Change Password	User Configuration	Delete User	

Click the button "User Configuration" to confirm your selection.



Next you have to check if the Mac-OS Optimization is marked.

a MDR		O Surveill								Motion Detec	tion is on Email Alarm is on	C-MOR-Stream
C-PICK		rt Menu		Quickst	art	Recor	dings	System	Administration		System Status	Logout
and you see more!	Cam 1	Cam 2	Cam 3	Cam 4	Cam 5	Cam 6						
Your are in the												
Menu User Configuration	Manag	ge User S	ettings									
User Permissions and Settings	Selecte	d User: mad	demo (Ma	ac Demo Us	er)							
Set which functions the selected user can use in the C-MOR web interface and if the web interface and the video recordings are	macde	mo (Mac Dem	no User)		•	Select Us	er					
optimized for MacOS or tablets.												
Livestream Speed and Browser optimization	User I	Rights an	d Settin	gs in the	Web Inte	erface						
For the use over Internet it can be useful to slow down the live stream to get faster downloads of recordings. Set the delay in this section.	0 .	The user ha	s the perm	ission to ch	ange the c	own passwo	rd					
Camera Permission		The user ha	s the perm	ission to vie	w the Qui	ckstart page	•					
Simply check the check mark of the camera for the user you want to grant access to the camera.	•	The user ha	s the perm	ission to vie	w the Rec	ordings pag	le					
Stream Type		The user ha	s the perm	ission to vie	w the Sys	temstatus p	age					
This configuration sets the default view mode for the live cam view for all users. The default C-MOR	0 .	The link to th	ne camera	will be view	ed to the i	user						
Stream Mode works in all browsers, but loads C-MOR and the PC or user device. MJPEG provides a	•	The user ha	s the perm	ission to set	t up the st	ream mode	and the vide	eo playback format se	lf			
smoother playback of the livestream, but is not supported by all browsers and is not always	0	The user ha	s the perm	ission to se	t up the M	otion Snaps	hot Preview	self				
User Settings for the Motion		Video record	dings and v	web interfac	e are optir	nized for Ma	acOS					
Snapshot Overview The preview image of the video		The video re	cordings	election tab	les are dis	played optir	nized for ta	blet computers				

Click "Save Configuration" afterwards.

2.7 Play Recordings

The playing of your recordings is the same procedure like saving. Just select "Open" the file when your browser asks you if you want to save or to open. Your Media-Player will start and play the recordings.

2.8 Delete Recordings

There are two options to delete recordings. In addition, you can select your recordings hours exactly. Cameras can be selected individually.



Delete Recordings



If you choose this option, your recordings will be deleted directly.

Under the Menu item "Delete Single Recordings" you can select a period of time of specific camera. In the next opened window, you can select each record individually for deletion.



Now the next opened window shows your recordings I a list.

	ection Recording 23:59:59 20	·		t Recordings Ca o 23:59:59 20				
Delete	Start Time	Bytes	Delete Start Time Byte					
No Recording	s found			15.05.20				
				13:00:00h	89326			
				12:00:00h	110148			
				11:00:00h	110150			
				10:00:00h	110212			
				09:00:00h	110365			
				08:00:00h	110265			
				07:00:00h	110246			
				06:00:00h	110249			
				05:00:00h	110238			
				04:00:00h	110230			
				03:00:00h	110261			
			~	02:00:00h	110274			
				01:00:00h	110326			
			~	00:00:00h	110305			

After marking the recordings you want to delete, you confirm your selection with clicking the "Delete Recordings" button.

Following a pop-up window appears, now you have to confirm once again your selection. This ensures that no important records are deleted accidentally.



Do you really want to c	lelete the selec	ted recordings?
	OK	Cancel



2.9 System Administration


Under "System Administration" you can define all important configuration settings in order to adjust C-MOR to your requirements and ensure a smooth operation in your network. The following sub chapters go into the details of the different configuration options.

ONDR	IP Video Surveillance Motion Detection is on Email Alarmis of V5.21 admin Diak Usage: 4%	on C-MOR-Stream
C-ITOIR	Start Menu 🔯 Quickstart Recordings System Administration System Status	Logout
and you see more!	Cam 1 Cam 2 Cam 3 Cam 4 Cam 5 Cam 6	
Your are in the	System Administration	
System Administration Menu		
System Name	System Name	open/close
Network Configuration		Openiciose
SSL Certificate	Network Configuration	open/close
Internet Proxy Configuration	SSL Certificate	open/close
Alarm Emails		
Time Setting	Proxy Server Configuration	open/close
Time Zone	Email Alarm	open/close
Time Server		<u>Open/close</u>
Maintenance Mode	Set Time	open/close
Archiving	Configuration of the Time Zone	open/close
Automatic deletion of oldest recordings		Openiciose
Cam Configuration	Time Server	open/close
User Administration	Maintenance Mode	open/close
FTP Server Configuration		
SFTP Server Configuration	Storage Time of Recordings	open/close
System Language	Automatic Deletion of oldest Recordings	open/close
Video Size Start Screen		
C-MOR Stacking	Camera Configuration	open/close
C-MOR Software Update	User Administration	open/close
License Upgrade		
Backups	FTP Server Configuration	open/close
System Restart	SFTP Server Configuration	open/close
System Shutdown		
	Language	open/close
	Start Page Configuration	[cnon/slass]
	Start Page Configuration	open/close
	Remote Access Configuration	open/close
	Stacking Slave Configuration	
	Stacking Slave Configuration	open/close
	Software Update	open/close
	License Upgrade	open/close
	License ohðtage	
	Backups	open/close
	System Restart	open/close
		Upen//close
	System Shutdown	open/close
	Start Page	
		open/close



2.10 System Status

Under "System Status" there is an overview listing status information of C-MOR. In the upper area you see your version number with the sum of your licensed cameras, your use disk space und your system utilization. In addition, under the system utilization, the operating time of your C-MOR is displayed. The operating time refers to how long your C-MOR is straight on. If a restart or system failure have happened, you recognize the fact that the operating time has started again from 0.






2.10.1 CPU Load

The CPU Load shows how much the system is used. This is important to realize if the C-MOR system is overloaded. Reasons for this are too much frames per second (fps) in motion detection mode or too big camera pictures in connection with additional cameras. It should be noted, the "Load" parameter refers to the used CPU cores or must be divided by this number. With a load of 1 and just one CPU core the system is running at 100 % on the CPU. With a Load of 1 and two CPU cores the system is running only 50%!

By clicking on the CPU usage graph you call the load graphics for "Daily", "Weekly", "Monthly" and "Yearly":



2.10.2 Camera availability and the Network Utilization

The middle part of this site shows you the camera availability and the Network Utilization of your C-MOR. Using these graphics utilization errors in the network can be detected. The graphics are divided in incoming network traffic (green line) and in outgoing network traffic (blue line).


Cam Availability in the Network

Cam 1 is available in the Network: 172.20.1.96, TCP-Port 554. Cam 2 is available in the Network: 172.20.1.81, TCP-Port 554. Cam 3 is available in the Network: 172.20.1.73, TCP-Port 554. Cam 4 is available in the Network: 172.20.1.54, TCP-Port 554. Cam 5 is available in the Network: 172.20.1.41, TCP-Port 554. Camera 6 is not active, no check for 192.168.1.16 on TCP-Port 80.

Camera Recordings

Recording for Cam 1 is active. Recording for Cam 2 is active. Recording for Cam 3 is active. Recording for Cam 4 is active. Recording for Cam 5 is active. Recording for Cam 6 is not active!

Network Utilization





2.10.3 System Log File

In the lower part of System Status the log files are shown which can be used to get support. Just copy and paste the Log into an email, and send it to the C-MOR support team. The Log File can be very useful to solve problems or to fix them.

```
System Log File
```

```
Nov 9 07:21:05 c-mor-v5 cam3: [1] [NTC] [STR] stream_stop: Closing stream listen socket & active stream
                                                                                                              ~
sockets
Nov 9 07:21:05 c-mor-v5 cam3: [1] [NTC] [STR] stream stop: Closed stream listen socket & active stream
sockets
Nov 9 07:21:07 c-mor-v5 cam3: [0] [NTC] [ALL] main: Threads finished
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] motion_startup: Using default log level (NTC) (6)
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] motion_startup: Motion 3.4.1+gite44a5a9 Started
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] motion_startup: Logging to syslog
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] motion startup: Using default log type (ALL)
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] motion startup: Using log type (ALL) log level (NTC)
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] become daemon: Motion going to daemon mode
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] motion startup: Motion running as daemon process
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ENC] ffmpeg_init: ffmpeg_LIBAVCODEC_BUILD 3747941 LIBAVFORMAT_BUILD
3746148
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] main: Stream port 9803
Nov 9 07:21:09 c-mor-v5 cam3: [0] [NTC] [ALL] main: Waiting for threads to finish, pid: 3652
Nov 9 07:21:10 c-mor-v5 cam3: [1] [NTC] [ALL] image_ring_resize: Resizing pre_capture buffer to 1 items
Nov 9 07:21:10 c-mor-v5 cam3: [1] [NTC] [DBL] motion init: Database backend mysql
Nov 9 07:21:10 c-mor-v5 cam3: [1] [NTC] [STR] http bindsock: stream testing : IPV4 addr: 127.0.0.1 port: 9803
Nov 9 07:21:10 c-mor-v5 cam3: [1] [NTC] [STR] http_bindsock: stream Bound : IPV4 addr: 127.0.0.1 port: 9803
Nov 9 07:21:10 c-mor-v5 cam3: [1] [NTC] [ALL] motion_init: Started stream server in port 9803 auth Disabled
Nov 9 07:21:10 c-mor-v5 cam3: [1] [NTC] [ALL] image_ring_resize: Resizing pre_capture buffer to 4 items
Nov 9 07:21:10 c-mor-v5 cam3: [1] [WRN] [NET] netcam next: called with no data in buffer
Nov 9 11:41:20 c-mor-v5 cam1: [1] [NTC] [STR] stream stop: Closing stream listen socket & active stream
sockets
Nov 9 11:41:20 c-mor-v5 cam1: [1] [NTC] [STR] stream stop: Closed stream listen socket & active stream
sockets
Nov 9 11:41:21 c-mor-v5 cam1: [0] [NTC] [ALL] main: Threads finished
Nov 9 11:41:22 c-mor-v5 cam2: [1] [NTC] [STR] stream_stop: Closing stream listen socket & active stream
sockets
Nov 9 11:41:22 c-mor-v5 cam2: [1] [NTC] [STR] stream stop: Closed stream listen socket & active stream
sockets
Nov 9 11:41:23 c-mor-v5 cam2: [0] [NTC] [ALL] main: Threads finished
Nov 9 11:41:24 c-mor-v5 cam3: [1] [NTC] [STR] stream_stop: Closing stream listen socket & active stream
sockets
Nov 9 11:41:24 c-mor-v5 cam3: [1] [NTC] [STR] stream stop: Closed stream listen socket & active stream
```



```
Mail Log File
```

```
Nov 10 12:02:31 c-mor-v5 [1417]: daemon started -- version 2.7.1, configuration /etc/
Nov 10 12:02:31 c-mor-v5 [149]: DE96D019716; message-id=<2016111012031.DE96D4019716@c-mor-v5.c-mor-video.com>
Nov 10 12:03:02 c-mor-v5 [147]: terminating on signal 15
Nov 10 12:03:02 c-mor-v5 [1785]: daemon started -- version 2.7.1, configuration /etc/
Nov 10 12:03:27 c-mor-v5 [1785]: relead -- version 2.7.1, configuration /etc/
Nov 10 12:03:27 c-mor-v5 [1785]: relead -- version 2.7.1, configuration /etc/
Nov 10 12:03:27 c-mor-v5 [1785]: relead -- version 2.7.1, configuration /etc/
Nov 10 12:03:27 c-mor-v5 [1785]: relead -- version 2.7.1, configuration /etc/
Nov 10 12:03:27 c-mor-v5 [1785]: relead -- version 2.7.1, configuration /etc/
Nov 10 12:03:27 c-mor-v5 [1785]: relead -- version 2.7.1, configuration /etc/
```

In support case you should "copy" the log file and "paste" it into the support-contact-form. You can find this form on <u>https://www.c-mor.com</u>.



2.11 Control with the iPad

You can use all functions of C-MOR with an iPad just like you can do with a desktop computer. But with the iPad you are mobile and you have your video surveillance always at your hand.

The following points characterize the iPad functions:


- Live view of many different camera models, even if the camera self has no direct iPad support
- Playback of motion, permanent or time-lapse recordings
- Watch single frames
- Just get started. There is no App installation required
- Control your PTZ cameras
- Receive alarm emails with video attachments
- And many, many more!

2.11.1 The Web Interface of the iPad

On the **Start Page** you find an overview of all functions for the operation and administration of C-MOR. If a camera is in recording mode, the Live View of the camera will appear here.

The web interface is same as the web interface of a normal web browser on your PC. Also, all features are available and the C-MOR web page is almost the same as you are used to with your PC.


In the Start Menu, you can see an overview of all installed cameras that can be accessed by C-MOR. You can touch on the camera live picture to select a single camera and watch the live view in a bigger picture or playback recordings.





2.11.2 Quickstart

The menu **Quickstart** shows the overview of all cameras, too. However, there is no Live View available in this menu. Here you just see static pictures updated every 15 seconds. If you have a small bandwidth connection of your iPad, this has the advantage, that you still have good access to the cameras. Here you can also choose the live stream, and you are able to play it with your iPad. If you are using C-MOR frequently through a low bandwidth connection it makes sense to bookmark this page as your C-MOR start page. It starts up faster than the other pages.





If you want to watch the live view of a camera, click on the button with the display size to open the live stream window.

If you click on the static picture in the "Quickstart" view, you will be forwarded to the Live View site of the respective camera. The Live View site can also be reached with the buttons Cam 1 Cam 2 Cam 3 etc. in the top menu.


2.11.3 Camera selection and live-view

On the camera page you have the Live View of the respective camera. The associated motion detection recordings and time-lapse are listed in the tables below the live stream.

2.11.3.1 Overview and Motion-Detection


Choose for example "Cam 1".

You can see a list of pictures which show you your recordings of your motion detection and your permanent recordings.






Your recordings are displayed as images. Just click on the button "Preview" to watch a little preview of your recordings. Just to check first what happened during the desired recording.





If you only want to see your motion detection recordings you can choose on the left side "Motion Detection" and then you have to click on "View Recordings".






After your selection you see following aspect:

●●○○○ Telekom.de 🗢			08:04				* 81 % 🔳)
$\langle \rangle$ m	1		.c-mor-\	/ideo.com		¢ î	+ 🗇
	7						
C-MOR a	nd you see more	Video sur	rveillance online demo	o of C-MOR. It works i	🕲 C	-MOR and you see mo	ore
	P Video Surveillar /5.01 admin Disk Usage: 4%	ice				lotion Detection is on Email Alarm is on	Script-Stream V
~	Start Menu	Quickstart	Recordings 5 Cam 6	System Ada	ninistration	System Status	Logout
and you see more! You are in the	Recordings: 00:00						
	Motion Detection C						
Cam Recordings	Haupteingang		12 10	0.20			1
The current display shows the resordings of the previously selected time frame. By selecting date and time a certain time period can be chosen. Motion Detection In the left column all recordings that have been generated due to motion detection are listed. Besides videos ti is also possible to display single frames that have been recording is activated in the configuration settings. Please select the number of movies you want to play, starting with the selected one. Movies can be selected until the end of the cordings to display. Permanent Recordings to display is to be selected until the end of the selecting the number of recordings to display.	Image: Preview Preview 201-10-12 07-48:49h 6009 KB Image: Preview Image: Preview	1 Preview 1 Preview 20 -10-12 07:45:58h 20 -10-12 07:45:58h 1244 KB Preview 1 Preview 20 -10-11 16:37:00h 2129 KB Preview 1 Preview 20 -10-11 15:48:40h 1893 KB 1		20 T Preview Frames 20 10-11 16.02-42h 3282 KB T Proview Frames 20 -10-11 15.32-14h 1099 KB	1 Preview Erames 20:::-10:-11 16:01:13h 20:::-10:-11 16:01:13h 1991 KB 1 Preview 1 Preview 20:::-10:-11 15:01:20h 1856 KB	Image: Teames Preview 20=0-0-11 15:54:57h 2083 KB 20=0-0-11 15:54:57h 2083 KB Image: Teames 20=0-11 14:48:39h 20=0-0-11 14:48:39h 2151 KB	




Here you have also the possibility to select the number of scenes you want see and you also can watch a preview of your recording.






Also you have the possibility to select only your permanent recordings and there you have the same functions like you have by choosing motion detection recordings






Now you see your permanent recordings. At this point you also have the possibility to view a preview of your recording, or to select the number of scenes.





Naturally you have the possibility to watch the complete recording and not only a preview. Therefore, you have to tab the picture of your desired recording and the film will start.





All PTZ (pan, tilt, zoom) functions are available for the iPad, too. Even if the connected IP camera does not support the iPad, it can be controlled through C-MOR since C-MOR acts as interface between the iPad and the IP camera. Further information about the PTZ Control you can find under *and 3.2.5*.





2.12 Mobile Devices

C-MOR offers 2 web interfaces for the use with mobile devices like Android phones, Windows Mobile, iPhone and others. 2 web addresses lead to these mobile interfaces:

/iphone: As the name says, for Apple iPhones

/mobile: For all other devices like Android and also for iPhones with an extra web browser like Chrome.

Both web interfaces do not require installing any App neither on the iPhone nor on Android to use it. Videos can be viewed as well as using the live view works straightforward.

If alarm videos are forwarded to an Android device and the recordings have a higher resolution, it may require using an additional video player on the Android phone. In this case we recommend the free MoboPlayer from the Android Play Store.

Notice

For the use of the functions you need access to the internet like UMTS or GPRS.

2.12.1 Display of recordings at mobile devices and Android

If you want to see the live view of your camera choose for example "cam 1". This button will leads you to the live view of camera 1.

You have the option to activate or deactivate "Motion Detection" or "Email Alarm" with a single klick.




By clicking on the link "Motion <cam no.>" the page with all motion recordings for the selected camera will




be opened. By clicking "Time-lapse" the page for all time-lapse recordings of the selected camera will be opened.

By clicking on **Overview** you will return to the main page.



If you have selected "motion 1" and you are touching the button "preview" it will open the quick preview of the selected recording on the same web page. The recording is identified by the time stamp in the left column of the table. The header shows the date of the recordings.

By clicking on the picture itself a window will pop up, offering either to save or to open recording. In case the data has already been connected to a specific player, the application will then open automatically and you will be able to view the recordings. Otherwise please open the video manually.





2.12.2 Display of Live Images on the iPhone


For the iPhone there is a separate interface available, to display live streams and videos on mobile Devices. If you are owner of an iPhone please use following link to show the camera overview on an iPhone:

http://<your IP address>/iphone

If you want to see the live view of your camera choose for example "cam 1". This button will leads you to the live view of camera 1.

You have the option to activate or deactivate "Motion Detection" or "Email Alarm" with a single klick.










By clicking on the link "Motion <cam no.>" the page with all motion recordings for the selected camera will be opened. By clicking "Time-lapse" the page for all time-lapse recordings of the selected camera will be opened.

By clicking on **Overview** you will return to the main page.



If you have selected "motion 1" and you are touching the button "preview" it will open the quick preview of the selected recording on the same web page. The recording is identified by the time stamp in the left column of the table. The header shows the date of the recordings.

By clicking on the picture itself a window will pop up, offering either to save or to open recording. In case the data has already been connected to a specific player, the application will then open automatically and you will be able to view the recordings. Otherwise please open the video manually.





3 Administration

3.1 System Administration

Under **System Administration** the user can define all important configuration settings in order to adjust C-MOR for a smooth operation in the network.

The following settings can be carried out over the system administration:

- Setting the System Name for email notifications
- Carry out network or/and IP settings
- Installation of a SSL-Certificate
- Proxy settings for internet access
- Configuration of email address for global system alerts
- Set time
- Configure time server
- Start/stop recordings (activate/deactivate camera)
- Define storage time for recordings per camera
- Auto delete in case of low storage space
- Setup the camera configuration of each camera
- User administration
- Configure Camera Rights and Stream Method for users
- FTP backup of recordings
- SFTP Server configuration
- Setting standard language (German or English)
- Presentation of the Start Page, size of Stream
- Remote Access without Dynamic DNS or router configuration
- Stacking configuration (combine up to 6 C-MORs with up to 90 cams)
- System reboot and Shutdown
- Software update and camera model update
- License Upgrade
- If activated, Barionet Alarm connection

The following sub chapters will describe you the details of the different configuration options.

3.1.1 System Name

Under **System Name** you can find the current system name of this C-MOR. The default system name is "C-MOR". Special characters should be avoided when setting up the system name.

System Name	open/close
The System Name is used in various parts and used in emails sent by this C-MOR. It is important to set the System Name.	
System Name: C-MOR Save System Name	

Mainly, the system name is used for easily distinguish your C-MORs from each other if you have more than one in operation. The system name is also used in all emails all sent from C-MOR and in various places in the user interface.

3.1.2 Change IP Settings

Under **Network Configuration** the current network configuration of C-MOR is displayed. There you can change the IP address settings of C-MOR, network mask, standard gateway and DNS server. The changes are immediately active, meaning that you can only reach C-MOR over the newly defined IP address. C-MOR continues working at that point!

IP Address:	192.168.1.2	
Network Mask:	255.255.255.0	
Gateway:	192.168.1.1	
DNS Server 1:	8.8.8	
DNS Server 2:	192.168.1.1	
DNS Domain:	c-mor-video.com	

By clicking "Change IP Settings" the following entry mask appears for adjustment of IP settings:

Network Adapter 1:						
IP Address:	172	. 20	. 1	. 237		
Network Mask:	255.25	255.255.255.0 ¥				
Gateway:	172	. 20	. 1	. 1		
DNS Server 1:	172	. 20	. 1	. 1		
DNS Server 2:	172	. 20	. 1	. 2		
DNS Domain: c-mor-video.com						
Save Configuration Reset IP Configuration						
Start Page						



After executing "Save IP Settings" C-MOR cannot be reached any more.

By entering the new IP address in the address field of your browser, C-MOR can immediately be reached again.

If you want to reset your IP Settings to default configuration you can choose the Button "Reset IP settings".

Network Configuration

The network configuration has been saved.

Network Adapt	er 1:
IP Address:	172.20.1.234
Network Mask:	255.255.255.0
Gateway:	172.20.1.1
DNS Server 1:	172.20.1.1
DNS Server 2:	8.8.8.8
DNS Domain:	c-mor-video.com

C-MOR with new IP Configuration

Important Note

Please take your time when changing the IP address!

C-MOR will immediately continue working under the new IP address!

Uncontrolled activation/deactivation can lead to data loss and other failures!



3.1.3 Generating and Installation of SSL-Certificates

SSL Certificate	open/close					
This function allows you to manage the SSL certificate for this C-MOR.						
SSL Certificate						

It is possible to generate a Request File (CSR) for a SSL Certificate with the 5th Version of C-MOR. With this file you can order a SSL-Certificate or generate one yourself. Bear in mind that a self-created certificate does not reach the same credibility as a purchased one.

To generate the necessary Request File (CSR) and the key (SSL Key), simply fill the correspondent forms.

SSL Certificate					
This SSL configuration page manages the SSL certificates on this C-MOR. C-MOR is delivered with a self-signed certificate. This certificate is not trustful. Therefore, this page provides the ability to install a certificate yourself and activate it. Please read the descriptions in the left menu.					
1 The C-MOR default certi	ficate is active. Activate a previously established SSL c	ertificate.			
Activate C-MOR generated Certific	cate (Re)activate self installed SSL Certificate				
Generate new SSL Certificat	te Request				
County Code (2 letter code)	DE				
State or Province Name	Baden-Würtemberg				
City	Hechingen				
Organization	za-Internet GmbH				
Complete Server name	my-c-mor.mydomain.com				
Generate Certificate Request					

Afterwards click the button "Generate Certificate". The following message should appear:

page provideo are ability to in	Stan a continente yourseir and activate it. I rease read the descriptions in the left menta.
The C-MOR default cert	ificate is active. Activate a previously established SSL certificate.
	int to generate the SSL Certificate now? An already installed SSL Key and the Request file (CSR) will be overridden!
Generate new S	
	OK Abbrechen
County Code (2 letter code)	DE
State or Province Name	Baden-Würtemberg
City	Hechingen

Click "OK" to generate both files

After this C-MOR will generate a CSR-file which will be shown in the CSR-text field. The CSR-file can be



used for the generation of certificate by a certificate authority. You can also let za-Internet generate the CSR-file for you. For the usage of a certificate it is important that the key suits to the certificate and the certificate-bundle (CA-Bundle). Precisely because these files have to match altogether therefore they can be CSR-file independent uploaded to C-MOR.

Certificate Signing Request (CSR)	
BEGIN CERTIFICATE REQUEST HICVDCCAaQCAQAwdzELMAkGA1UEBhMCREUxGTAXBgNVBAgUEEJhZGVuLVf8cnR1 GWJ1cmcxEjAQBgNVBAcTCUhlY2hpbmdlbjEZMBcGA1UEChMQemEtSW50ZXJuZXQg R21iSDEeMBwGA1UEAxMVDXktYy1b3IubX1kb21haW4uY29tMIIBIjANBgkqhkiG 9w0BAQEFAAOCAQ8AMIIBCgKCAQQEAOV5IwTdrhBjTD+H4hEIFLZf05C2bujoyqAfe J41gy77Zhk7/A5ytoNRu3nLtSmn/EJpEpvCGdVED7KSyLDfQnLONqpwsRFCUgpo JhGQCNxgevnn64KOrhTTBXX4x1T70A0v1MXWwfdcI9yh1qIOhCGZaUg9dCoHTyip FC8btZYXB1gsK87yHJto1hCOeG6E21JjtNiEfzSN+ye07XzuzY17bnuRjrsu1709 HcsiU8J08Rrv81VVVvrUhXN0RMDraEGupeJU9B01RveXUcaKMOhLVVP2TRyAcmw1 JNY20wCNo122W3gJIYe+qCu32f614TUs6AXPZA81a4tBSockCwIDAQABoAAwDQYJ KoZIhvcNAQEFBQADggEBAKg1sNKM5QsH00MfdM1qIokoj5sE9TVL0sv5EWSh33w1 JNgMaDVh2tDgFp4kd5PR18AGCKj0M71/9uyq1jmb2x0tmPyt44up61gw6u0djxtY FX2dpaJ2zXuP5120cxJ8fhUAXSvOPMBd1M9Y2011uKYuEhXhWaScBMJXV+kVuM s20xVmQSFVenF207yxkvOIugyGEoOTUa2LgxxT0UpSYKaKXXvLo8yrU5YH61Mj BHqSHb1bDSx2nw2TrP8BzW1MyYVYYL5zs4yQFP2cqf2X0eOGMA1scWK2svQdp1hR 1Wiwb1Tm1EpGc4sVr4PcNswQ751MVzUZHznKxz2PZ0Y= END CERTIFICATE REQUEST	
SSL Key BEGIN RSA PRIVATE KEY HIEPAIBAAKCAQEAOV51wTdrhBjTD+H4hEIFLZfO5CZbujoyqAfeU41gy77Zhk7/ /a5ytoWRu3nLtSmn/EJDEpvCGdVED7K9XDfqDnLONqpwsRFCUgpoJnGQCNxgevnn 64KOrhTTBXX4x1T70AOv1MXW#fdcI9yh1qI0hCG2aUg9dCoHTyipfC8bt2YXB1Qs K87yHJto1hCOeG6Z1JjtNiEfz5N+yeO7Xzu2Y17bnuRjrsu17o9RcsiUBJO8Rrv 81VVVvrUhXNORMDraEGupeJU9B01RveXUcaKMOhLVVP2TRyAcmw1jNY2OwCNo122 N3gJIYe+qCu32f6i4TUJ6AXP2A81a4tBSockCwIDAQBAoIBADEJFKYsMJKXFOn0 MdQIfpiduV04Y0ZK/dqLxjUK1+nZh8nKvq+2Anwtyu8Z/aIt/Zvppi1U3vAbKlcY 1VJOu5Lc90LFi58y8sK4aIsOsiQyPH6AK1sOkBfxEImF33ZAzryca65fJDDvsTNE 88Lg09FU5WFdL/cUahS8VIQ6ErsWuK/GX/i27NIy9/PYJpQ2VrOQGdisgmuquP 65Cup+0PT29hWezq1GRoE+me6S9+eQi72SUTV/sAXx6pi1FHhPqxxxQU4hrNyr 1044iAigaKQOeEImGqCRbJiuq7o2JJ1ApIh5M5iwY22uuV/QD2gmNoeP1sdM7f r8XcwaECgYEA9xWVuaiD9iQc01POMzXYwGvkuR017mV1sy3qiTrO4uAqdYGbQoLa 215PPd77Cgsdd9hK9xhyQjwUHUomB11w4hf638SA2amv6voYjVxGm+n2I6G1i DC82pXbp061/f8A1aRx7hewJRUt8wmBQpuxfgs8p2UH1pv1Lp2vo69EcgYEA20xN WYQQKnhKOvcSKfUGaZVQMNfmXfHqLHMz9BKWE7Y9RT98v32brMjhrY1dBj0uM1i 1UUKUVTsnRoqDqgcxGUQLJ65gD0PHo6jmBPvDeV0fUH/Auw855FTRNTJhygcpJm nuk91FFTYhJDh5JgcdBesm+MxP03SFj0v1IKNRcGYEAu8LRVp2yQffLo59P0KaY 0hDbbLhdsxuyx4ia89GWqd2DJmxpGa/qzIIuWWAP8bDDgIdR1VThki2S9VHACCB 76nQ11qzy96Nt77WpBunxmw9CU1RtJcAS8i0jcUodERcY/kDKuw2RM3zWwBt2+ LDrvsBNhT9HJ5SsIJHahviECgYEAx7ipTxU20jS8ASVH6E0923BRx5IfDvNNhnBN Ini8m1r+PohZWEHHCt08tGcdWwcwyi7J1gFq+R5Bhx05JG8CsB1YLyVDPXm9bQ 0hC2pT3CByGgXVyAudjbDZ/h5pH12DQ22Qd7UH1it8t9cC7s4624cf639QUhmkB FornNEKCgYBGHQCgvB+jujLbTNCY4FcginLTa2Dzjal5SOF618yuziJxcURvbvo 5hegpozFidmJrR+ETYwDBbr5J4owFYG98cr8e+UAz7HMOREnspoz6WCQKhc13ueX VCfEUSBAAEPKF7HrCwkdnH88U0Gs56A1S301S1108IgS9EyUQ9Ujg== END RSA PRIVATE KEY	

If you have generated a CSR-file and a Key yourself they will be shown like here at the C-MOR -interface.




After you got a SSL-Certificate or did generate one yourself. You can upload it to C-MOR by copy and paste function of your browser. For this the 3 files SSL-Key, SSL-CRT and SSL-CA-Bundle are necessary. You can get these files through your SSL-Certificate Agency. Copy this data into the appropriate text boxes:

~

SSL Key
BEGIN RSA PRIVATE KEY MIIEpAIBAAKCAQEAOVSIwTdrhBjTD+H4hEIFLZfOSCZbujoyqAfeU4lgy77Zhk7/ /a5ytoWRu3nLtSmn/EJpEpvCGdVED7K9XDfqDnLONqpwsRFCUgpoJnQcNxgevnn 64KOrhTTBXX4x1T70A0v1MXWwfdcI9yh1qIOhCGZug9dCoHTyipfC8btZYXB1Qs K87yHJto1hCOeG6Z1JjtN1EfzSN+ye07Xzu2Y17bnuRjrsu17o9Hcs1U8JO8rv 81VVVrUhXNORMDraEGupeJU9B01RveXUcaKNOhLVVPZTRyAcmw1jNY2OwCNol22 W3gJIYe+qCu32f6i4TUs6AXP2A81a4tBSockCwIDAQABAoIBADEjFKYsMJKXFONO WdQ1fpiduVO4Y02K/dqLxjUK1+n2h8nKvq+2Anvtyu8Z/a1t/Zvpj1U3vAbK1cY 1vJOuSLc90LFi58y8sK4aIsOsiQyPH6AKIsOkBfxETmF33ZAzryca65fJDDvsfNE s8Lg09FU5Wrd1/cUahS8V1Q6ErsWuK/GX/127W1y9/yTtJpQ2VrOQGdisgmuquP 6jCup+OPT29hWezqIGRoE+me6S9+eQ172SUTV/sAXx6piIFhHpgxvxQxU4hzNyr Ud14iAigaRQOeEImGqCRbJuq702LJ1ApIh5MSiwrY2suUV/QD2gmMoeqP1sdM7f r8XcwaECgYEA9xWVua199iQcO1POMzXYwGvkuR017mV1sy3qiTr04uAqdYGbQcLa +z15PPd77CQsdd9hk9xhQjwlWHuOmB11w4hf638SA8Zamv6voJyVGm+n216G1i DCB2pXbp061/f8A1ax7hewJRU58mBQpuxfqsBp2UH1pv1LpzYo69ECgYEA20xN NvYQOKmhK0vcSKfUGaZVQmNfmXfHqLHM29BKwE7Y9R798vw2brMjhrYIdBj0W1i 1UUKUVTsnRoqDqcxcGQLJ65gD0PHo6jmBPvDeV0fUH/Auwv855FTRNJJnygcpJm hu891FTYhJDh5JgcdBesm+MzP035Pj011kNRsGYEABUKP22yQfTL659P0KaY ohDbbLhdsxuyx41a89GWqd2DJmxpGa/qzIIuWWAP8bDDgIdR1VThki259VHAOCB +76nQ1qzy96Nt7WpBunxmv9CUIRJcAS810jcUcd8ER0Y/kDKw2RM3ZWMBt2+ LDrvsBNhT9HJ5SsIJHahviECgYEAx71pTXU20jSASVH6E09Z3BRX5IfDvnNhnBN 1n18m1+PonZWEHHCt08tGcdWWcwyxj/T1gFq+R5Bhx05JG8Csb5IYLYDFMsbQ oNC2pT3CByGqXVAudjbDZ/hSpH12Qa2dQd7UH1t8t9cC7s4624cf639QUmkB TcnrnkcGYBGHQgvBJ+juJLDNCY4FcginLTa2Dzja1S50F618yu1JxURV8vo 5hegpozFidmJrR+ETYwDBbt5J4owYYGp8crBe+U3z7HM0Enspoz&WCQKcl3ueX nVCfeUsBaAEPKF7HrCwkdnHS8U0Gs56A1S301SI108IgS9EyUQ9Ujg== END RSA PRIVATE KEY
SSL Certificate (CRT)
LDrvsBNhT9HJ5SsTjHahviECgYEAx7ipTxU20jS8ASVH6E0923BRx5IfDvnNhnBN hitBml++PohZWEMHCt08tGcdWWcwyxj/T1gFq+R5Bhx05JG8Csb5IYLyVDPXm9bQ oNC2pT3CByGgXVyAudjbDZ/hSpH12DQa2dQd7UHIit8t9cC7s46Z4cf639QUhmkB TcnrNEkCgYB6HQCqvBJ+jujLbTNCY4FcginLTa2Dzjal550F618yuziJxcURv8vo ShegpozFidmJrR+ETYWDBbr5J4owPYGp8crBe+UAz7HMOREnspoz6WCQKhcl3ueX nVCfeUBBAAEPKF7HrCwkdnHS8UOCsS6A1S301S11081g59EyUQ9UdfgD5FGdsfgd MIIEpAIBAAKCAQEAOV5IWTdrhBjTD+H4hEIFLZf05C2bujoyqAfeU41gy772hk7/ /a5ytoWRu3nLtSmn/EJpEpvCGVED7KSyDfqDnLONqpwsRFCUgpOJNGQCNxgevnn 64K0rhTBXX*x1T70A0Y1MXWwfdcI9yh1qI0hCGZaUg9dCoHTyipfC8btZYXB1Qs K87yHJt01hC0eG6E21JjtNiEfz5N+ye07Xzu2Y17bnuRjrsu1709Hcs1U8J08Rrv 81VVVvUNXN0MDraEGupeJU9B01RveXUcaKM0hLVVPZTRyAcmw1jNY20wCNo122 W3gJIYe+qC132f6i4TU96AXF2A81a4tB5ockCwIDAQABA0IBADEjFKYSMJKXF0n0 WdQ1fpiduV04Y0zK/dqLxjUK1+n2h8nKvq+2Anwtyu8Z/a1L/Zvppi1U3vAbKlcY 1vJ0u5Lc90LF158y8sK4aIs0siQyH6AKls0kBfxETmF33ZAzryca65fJDDvsfNE s8Lg09FU5WFdL/cUahS8VIQ6ErsWuK/GX/127W199/PytJpQ2VOQGdisgmuqP 6jCup+0PT29hWezq1GRoE+me6S9+eQ172SUTV/sAXx6piIFHhPqxvxQU4hzNyr Ud14iAigaKQ0eEIm6qCRbJiuq702LJ1ApIh5MSiwr22suU/QD2gmMoeqP1sdM7f r8XcwaECgYEA9xWVua1D9iQc01P0MzXWGvkuR017mV1sy3q1Tr04uAqdYGbQoLa +15PPd77Cgadd9hs9xhQjWHWuCMBIWih6S832Zamv6v70YJYGm+1216G1i DC2p2bp061/f8A1aR7newJRUt8wmBQpuxfqs8p2UH1pv1LpzYo69ECgYEA20xN NvYQ0KmhK0vcSKfUGaZVQmNFmXHqLHz9BKwE7Y9RT98vw2brMjhrYIdBj0Wli 1UUKUVTsnRoqDqgcxGUQLJ65gD0Ph6jmBPvDeV0fUH/Auw855FTRNJJhygcJm huk91FFTYhDbh5JgcdBesmHxPadfgdjg3ga0pie%\$6y35w51fDvnNhnBN n18m1++PohZWEMHCt08tGcdWwxyj/T1gFq+R5Bhx05JG8CabSIYLyVDPXm9bQ oNC2pT3CByGgVyAudjbDZ/hSpH12Qa2dqd7UH1it8t9cC7s46246f39QUMkB TcnrNEKCgYB6HQCqvBJ+juJLDNCY4FqinLTa2Jja1SD67618yuziJxcURv8vo ShegpozFidmJrR+ETYWDBbr5J40wPYGp8crBe+UA27HM0REnspoz6WCQKhc13ueX nVCfcUBBAAEPKF7HrCwkdnHS8U0Gs56A1S301S1108Ig59EyUQ9Ujg== END_CERTIFICATE
BEGIN CERTIFICATE

----BEGIN CERTIFICATE----TcnrNEkCgYBGHQCgvBJ+jujLbTNCY4FcginLTa2DzjalS50F618yuziJxcURv8vo ShegpozTidmJzR+ETYWDBbr5J4owPYGp8crBe+UAz7HMOREnspoz6WCQKhcl3ueX nVCfeUsBaAEPKF7HrCwkdnHS8U0Gs56A1S301S1108Ig59EyUQ9UdfgD5FGdsfgd MIIEpAIBAAKCAQEA0V51wTdrhBjTD+H4hEIFLZf05C2bujoyqAfeU4lgy772hk7/ /a5ytoWRu3nL5sm/EJpEpvCGdVED7K9XDfqDhLONqpwsRFCUgpoJnGQCNxgevnn 64K0rhTTBXX4x1T70A0v1MXWwfdcI9yh1q10hCG2aUg9dCoHTyipfC8bt2YXB1Qs K87yHJto1hC0eG6Z21JjtNiEfz5N+ye07Xzu2Y17bnu8jrsu17o9Kcs1U8J08Rrv 81VVVrUhXN0RMDraEGupeJU9B01RveXUcaKM0hLVVP2TRyAcmw1jNY20wCNo122 W3gJIYe+qCu32f614TUs6AXPzA81a4tBSockCwIDAQABA0IBADEjFKYsMJKXF0n0 WdQIfpiduV04Y0ZK/dqLxjUK1+n2h8nKvq+2Anwtyu8Z/aIt/Zvppi1U3vAbKlcY 1vJ0uSLe90LF158y8sK4aIs0siQyH6AKIs0kBfkETmF33ZAzryca65fJDDvsfNE s8Lg09FUSWFdL/cUahS88VIQ6ErsWuK/GX/127W1y9/pYtJpQ2Vr0QGdisgmuquP djCup+0PT29hWezq1GRoE+me6S9+eQ17ZSUTV/sAXx6piIFHhPgxvxQzU4nzNyr UdI4iAigaKQ0eEImGqCRbJiuq702LJ1ApIh5MSiwrY2suuV/QD2gmMoeqPlsdM7f r8XcwaECgYEA9xWUaiD9iQc01P0M2XWGvkuR017mV1sy3qiTr04uAqdYGbQ0La +z15PPd77C0sdd9hk9xhv0iwJWHu0mBi1w4hf6385A8Zamv6voV1VxGm+n216GIi After the upload the certificate will be saved by clicking "Install SSL-Certificate". A correspondent message appears:



Confirm the message by clicking on OK

The SSL certificate has been successfully installied. It still must be activated!
OK Abbrechen

Also confirm the second message by clicking OK

If the upload was successful the button for the activation of your own SSL-certificate will be active.

The C-MOR default certificat	e is active. Activate a previously established SSL certificate.	
Activate C-MOR generated Certificate	(Re)activate self installed SSL Certificate	

Finally the uploaded certificate must be activated. Click on the button "Activate Self installed SSL-Certificate". The following messages will appear:

The self installed SSL certificate was activated. Please click reload on the	browser if the connection is lost.
	OK Abbrechen

Confirm with a click on OK



The SSL configuration has been changed. Please the configuration has been switched successfully SSL configuration because of an error.	
	OK Abbrechen

Please also confirm the second message. Afterwards the certificate will be activated and C-MOR checks if the new certificate is usable. A succeed will be shown trough a green icon at the SSL-page.

A self installed SSL certificate is active.					
Activate C-MOR generated Certificate	(Re)activate self installed SSL Certificate				

If the certificate you have just installed doesn't work C-MOR will use the standard-certificate but is however available for you.

Now you can use C-MOR with a SSL-certificate. Show up the C-MOR by typing <u>https://<your-c-mor-ip</u>> into the URL-bar.

Note

A certificate only works with the correct URL-Name. Although you called C-MOR with an IP address e.g. <u>https://192.168.1.2</u> a warning will be shown!

With version 5.01PL04 the SSL certificates can be switched through the VGA Text Console! Please use this feature in the case your C-MOR SSL configuration got corrupt to recover web access!

More information regarding the order of a SSL-Certificate is available at our homepage <u>https://za-internet.de/sicherheit/ssl-zertifikate.html</u>. We look forward to assisting you in selecting the optimal solution.

3.1.4 Proxy-Server Configuration

	itemet with this proxy settings.
Proxy is active	
IP address/DNS Name	
TCP-IP-Port	
Username	
Password	
Save Configuration	

C MOD con access the Internet with this provy settings

If you use a proxy server for the connection to the internet you can enter the information here.

3.1.5 Email Alarm Configuration

C-MOR offers the possibility to send an e-mail to a registered address when different events occur. C-MOR keeps you up to date when something happens. Even if you are far away. If a camera fails, you will be notified by C-MOR. C-MOR will also notify you when this camera is available again. You can find further settings for e-mail alarms in the submenu "Camera configuration - E-mail alert" in this manual.

At System Administration under configuration e-mail alarm it is possible to enter your email address. All emails generated by C-MOR will be sent to the address defined. After having entered and saved an email address and relay host it is possible to send a test mail to check if the configuration is correct.

Since C-MOR Version 4.11 PL10, it is possible to enter more email addresses. You have just to separate them with a comma.

Besides this function there is the possibility to enter settings for the SMTP authentication. SMTP authentication covers the incoming mail server, user name and password that allow the sending of emails over the mail server of your provider. Many email providers use this technology in order to ensure that the sender of an email is authentic. Another setting which may be required by your provider is SSL encryption. Simply enable this feature by clicking on the checkbox. Make sure the select TCP-Port is set correctly. The standard port for not encrypted emails is 25 (SMTP). The standard port for SSL emails is 465.



(open/close)

Email Alarm

All emails that are generated by the system will be sent to the administrator address. The email addresses for camera alerts are stored in the camera configurations. The settings on the relay host define the server the emails will be sent to.


Email Alarm Address:	cmoruser@customer.com, cmor2user@custom
Relayhost:	mail.customer.com
TCP-IP-Port:	465
SMTP authentification activated:	1
SMTP SSL Communication activated:	v
Username for SMTP authentification:	cmor
Password for SMTP authentification:	
SMTP Sender Address:	cmor@customer.com
Save Email Settings	
Send Test Email	

If a camera fails the following mail will be sent by C-MOR:

	20.09.2017 07:54	
	C-MOR : Cam 1 Server is not available	
-		
C-MOR		
	Attention! The cam 1 Front is not available!	



C-MOR can be configured to send an Email when the motion detection takes effect. Furthermore C-MOR can be configured to attach a short video-clip to the Email that shows the event that triggered the alarm.



Motion detected: Front on 02.11.20 15:04:19



You can directly watch these clips of the Email. Just click on the video. You can also right click the video to open a context menu. Then choose Preview.

02.11.20 15:06 C-MOR C-MOR Front Motion detected Ca	m 1 on 02.11.2(, 15:06:01	
C-MOR Motion detected: Front on 02.11.20 . 15:06:01		
C-MOR C-MOR C-MOR Front Motion detected Ca		
am1-736266762796-20 1102150601-01	mp4 (2 MB)	
C-MOR Motion detected: Front on 02.11.2(15:06:01	Preview Qpen Quick Print Save As Save All Attachments Remove Attachment Copy Select All	

You can find more information about Email alarm under Camera-Configuration.

Note

Please keep in mind that your Email-box can run out of space very fast if C-MORs motion detection takes effect. E.g. by moving trees through wind or rain and snowfall.



3.1.6 Set Time

Here it is possible to adjust time and date. In order to make sure that the recordings of C-MOR have the correct time stamp it is necessary to set the exact time and date.

Set Time)	_		_
Time: 17:37 Date: 12.10				
Time: 17	: 37	: 47	(Hours:Minutes:Seconds)	
Date: 12	. 10	. 2015	(Day.Month.Year)	
Set Time	and Date			

3.1.7 Configuration of Time Zone

Here the user is able to set the relevant time zone.

Time: 17:4				
Date: 12.1	0.201	5		
Select new	Tim	e Zone:		
America	•	New_York	•	



3.1.8 Time Server Configuration

With this menu item the automated configuration of the time for C-MOR can be carried out. The supported time protocol is Network Time Protocol (NTP).

Time Server
Catura the Times are a form which the time and date is supplying indict sinks extend to the
Setup the Timeserver from which the time and date is synchronized at night automatically.
Time Server: pool.ntp.org
Check Time Server
Delete Time Server

Note

When setting this option please make sure that the internet connection to the time server is always active. In case the time server cannot be reached or delivers wrong data, the time on C-MOR will not be correct.

Examples for time servers:

- ntp-1.vt.edu
- ntp-2.vt.edu

3.1.9 Maintenance Mode, activation and deactivation of Recordings

This menu item allows you to activate or deactivate recordings for the individual cameras. This is the same function as on the respective camera configuration page. Also, enable the Maintenance Mode in this menu prior installing software updates on the C-MOR.

Maintenance Mode	
Recording Camera1: activated Stop Recording	
Recording Camera2: deactivated Start Recording	
Recording Camera3: deactivated Start Recording	
The Maintenance Mode is not enabled. Activate Maintenance Mode	

3.1.10 Storage Time of Recordings

By setting the storage time it is defined after how many days C-MOR recordings will be automatically deleted. Deletions by C-MOR are carried out at night-time. The deletion includes all types of recordings, motion detection recordings, single frames and fast motion recordings. This settings can also be found on respective camera page.

Storage Time of Recordings		_		
Camera 1: delete Recordings after 10	Ŧ	days	Save	
Camera 2: delete Recordings after 10	۲	days	Save	
Camera 3: delete Recordings after 10	Ŧ	days	Save	



3.1.11 Automated Deletion of oldest Recordings

Irrespective of storage time settings, recordings can be automatically deleted. This enables C-MOR to continue recording instead of stopping when storage space is running low. Please be aware that automated deletion can lead to recordings being deleted too early and important video material getting lost.




Note

If more Data is generated than deleted you are at risk, that you are running out of storage.

3.1.12 Change Camera Configuration

For each individual camera an own configuration page is available where parameters can be set. First you can visit the page "System Administration" where you will find "Camera Configuration". Or you can click on the button the requested camera and then the link "Cam Configuration".

Camera Configuration	
Change Configuration Camera 1	Entrance
Change Configuration Camera 2]
Change Configuration Camera 3	1



Please find more information on camera configuration in chapter 3.2.



3.1.13 User Administration

Under this section it is possible to create, rename and delete users and change passwords. By clicking the respective button, you will be forwarded to the user administration page where it is possible to enter the password, or reach directly the configuration page for the selected user.

User Administ	ration		(open/close)
User	Display Name	Change Password User Configu	ration Delete User
admin	Administrator Change Display Name	Change Password User Config	
tester	michaelr Change Display Name	Change Password User Config	uration Delete User
New User:	Display Name:	Create User	

Note

Only administrators are able to delete recordings or change the settings of the C-MOR configuration.

3.1.14 Access Control according to the two man rule

It is possible to setup a access control according to the two man rule. This rule states that important decisions or changes should not be performed by a single person. Only two authorized instances are allowed to make changes. This rule also says that 4 eyes see more than two. This kind of access can be wise to ensure all Data is protected from access and modification of a single user.

For this a module will be added to C-MOR which allows two users to be set up. The individual users will not be authorized to access the system or take a change. Only the authentication of both users enables granted access to C-MOR and the storage device.

Possible fields of application are given when access control requires the presence of two persons. For example if the data is relevant as an evidence. And to prevent concealment.

Note

Please feel free to contact our support if you have any questions regarding this topic.



3.1.15 Setup User Settings and Permissions

For every created user you can setup different configurations. As desired by the administrator, users can change the configuration of the **System Administration** or not.

The following parameters can be changed by the user, if a user is selected to configure the own profile:

- The user is able to change the own password
- The user is able to view the Quickstart page
- The user is able to view the Recordings page
- The user is able to view the System Status page
- The user is able to view the link to the camera
- The user is able to setup the stream mode
- The user is able to setup the speed of the Script-Stream Mode
- The user has the permission to set up the Motion Snapshot Preview self
- Video recordings and web interface are optimized for MacOS
- The video recordings tables are displayed with an extra preview button for tablet computers

Access to the single camera views and to the recordings can be restricted to single users. Different user can have access to different cameras and/or camera recordings. The live stream type, Java stream, MJPEG stream or script stream, can be set by the user self if permitted by the administrator.

In the System Administration menu under User Camera Rights Administration and Live Stream Mode Settings the administrator can setup the camera and stream permissions. Select the user to modify and click User Configuration.

User	Display Name	Change Password	User Configuration	Delete User
admin	Administrator Change Display Name	Change Password	User Configuration	
New User:	Display Name:	Create User]	



Manager	LIDOR	Cattingen	
Manage	User	settings	

Selected User: admin (Administrator)

admin (Administrator) 🗸 Select User

User	r Rights and Settings in the Web Interface
	The user has the permission to change the own password
	The user has the permission to view the Quickstart page
	The user has the permission to view the Recordings page
	The user has the permission to view the Systemstatus page
	The link to the camera will be viewed to the user
	The user has the permission to set up the stream mode and the video playback format self
	The user has the permission to set up the Motion Snapshot Preview self
	Video recordings and web interface are optimized for MacOS
	The video recordings selection tables are displayed optimized for tablet computers
Live Stream Speed in Script-Stream Mode	
Delay in seconds in Script-Stream live view 0 🗸 Seconds	



The lower part of the User Configuration page:

Manage Camera Rights		
Permit Camera Access Permit Recordings Access		
Camera 1 🗹 Camera 1 🗹		
Camera 2 🗹 Camera 2 🗹		
Camera 3 🗹 Camera 3 🗹		
Save Configuration		
Stream Type Configuration Ive View as Script-Stream Live View with Java-Player		
O Live View as MJPEG-Stream		
Save Live View Mode		
User Settings for the Motion Snapshot Overview		
Pixel width of the preview pictures in the web interface $142 \sim$ Pixel		
Pixel width of the preview pictures in the mobile interface $142 \sim$ Pixel		
Pixel width of the preview movie in the web interface $320 \vee$ Pixel		
Pixel width of the preview movie in the mobile interface $\boxed{320}$ \checkmark Pixel		
Save Preview Configuration		

Further you can set up the live stream Speed, the camera rights and the stream type for the chosen user.

Select the cameras that can be accessed by the user. If a camera is completely locked for the user, the access to the recordings is locked, too.

If the user should have access to the live view of the camera but not to the recordings, disable the mark in **Permit Recording Access** at the relevant camera.

Please make the settings for the preview pictures and videos In the last section of the user configuration page. The configuration is split between the mobile view and the desktop web view of C-MOR.




3.1.16 FTP Server Configuration

By the use of the so-called File Transfer Protocol (FTP) recordings can be automatically copied to a FTP server. A FTP server can be a desktop PC with Windows operating system and FTP server software. By the help of FTP long-term storage or tape backup can be carried out.

Besides easy FTP server storage, C-MOR can also delete recordings after the copy process.

FTP Server Cont	figuration	
FTP upload activated before deletion?	0	
FTP Server Address:	10.10.1.1	
Directory:	/data/	(please add closing "/")
Username	ftpdemo	
Password	•••••	
Save FTP Settings		

Use the "Recordings" menu to manually upload recordings to the FTP Server





3.1.17 SFTP Server Configuration

With the encrypted FTP protocol SFTP, video recordings can be downloaded from the C-MOR via a SFTP client such as Filezilla or via a SFTP command. This allows multiple recordings to be backuped, for example, on an USB stick, or to program an automatic recordings backup. The user name is static set to 'download'. The TCP Port number is 9442. You can enable the SFTP account and set download permissions for each camera.

SFTP Server Configuration
SFTP User activated: (TCP-Port: 9442)
The SFTP User has the predefined user name 'download'.
SFTP User Password:
The SFTP user has access to following cameras:
Camera 1: 🗹 Camera 2: 🔽 Camera 3: 🔽
Save SFTP Settings

3.1.18 Language

The C-MOR application is available in German and English. By using this menu item the standard language can be set, which will then be used automatically as soon as you log into C-MOR. Alternatively it is possible to choose the language by clicking on the country flags on the top right edge in the menu which can be enabled with the Show Country Banners settings.

Language	
— 0	German
	English
Show Country Banners on top right corner in the Web Interface: \Box	
Save Language Settings	

If you want to temporarily change the language you can go to the upper right side of the Start Page. Here you will find the flags of the supported languages. Choose one of the flags to choose the language you prefer.





3.1.19 Start Page Configuration

Start Page Configuration
 Classic View 4:3 (Variable Stream Sizes)
 Classic View 8:5 (Variable Stream Sizes)
 Classic View 16:9 (Variable Stream Sizes)
 Classic View 19:10 (Variable Stream Sizes)
 Classic View Small 4:3 (Stream Sizes in 320x240 Pixel)
 Classic View Small 8:5 (Stream Sizes in 320x200 Pixel)
 Classic View Small 16:9 (Stream Sizes in 320x180 Pixel)
 Classic View Small 19:10 (Stream Sizes in 320x168 Pixel)
Save Start Page configuration

Here you have the option between different stream sizes to choose.

3.1.20 Remote Access

With the C-MOR remote access it is possible to access C-MOR without dynamic DNS. This function is required if dynamic DNS can't be used or if it's not possible to configure port forwarding on the Internet router where the C-MOR is connected. There may be many reasons that the remote access from C-MOR is required and this is just another, easy option to access C-MOR over Internet.

The remote access is implemented through a server in C-MORs (za-internets) data center. The access requires a monthly fee. Please find more info in the C-MOR web, <u>www.c-mor.com</u>.

The configuration for the remote access can be found in the "System Administration" configuration page of C-MOR video surveillance.

Remote Access Configuration	open/close
This configuration menu performs the remote access configuration.	
Internet Remote Access is not active.	
Activate Remote Access	
HTTPS Transfer Server Port 0 (automatically assigned) Username Password	
To get remote access via the Internet to your C-MOR, you must first register a paid subscription. This registration is available at <u>www.c-mor.com</u> .	
If the remote access is set up you can reach your C-MOR via an address like https://remote.c-mor.com:64444. The so-called port number (example 64444) is and awarded for you individually!	always reserved



The following data are required to set up remote access:

Server:	The server name which connects to your C-MOR
Username:	The username for the remote access, cmorremote <xxxxx></xxxxx>
Password:	The password for the remote access

The data above, as well as the TCP-IP port are assigned by C-MOR and can't be changed. The TCP-IP port will be assigned automatically and read over Internet. Customers receive the data above by email. The remote access address is a combination of the server name and the port. If the server name e.g. is "remote.c-mor.com" and the port "10001", the web address is <u>http://remote.c-mor.com:10001</u>.


Additional it is possible to select whether the remote access is done via SSL (HTTPS) encryption. If SSL is enabled, the web address is <u>https://remote.c-mor.com:10001</u> instead <u>http://remote.c-mor.com:10001</u>.

Enter the data for the remote access and click "Save Configuration". Alternatively SSL (HTTPS) encryption can be selected:

Remote Acc	cess Configuration	open/close			
This configuration menu performs the remote access configuration.					
Internet Remote Access is not active.					
Activate Rem	lote Access				
HTTPS Transfer	r 🗆				
Server	remote.c-mor.com				
Port	0 (automatically assigned)				
Username	cmorremote				
Password	•••••				
Save Configu	ration				
To get remote access via the Internet to your C-MOR, you must first register a paid subscription. This registration is available at www.c-mor.com.					

If the remote access is set up you can reach your C-MOR via an address like https://remote.c-mor.com:64444. The so-called port number (example 64444) is always reserved and awarded for you individually!

The saved configuration is displayed after clicking "Save Configuration":



Please notice that the remote access is not enabled yet. Please click on "Activate Remote Access" to enable it:

C-MOR	IP Video Surveillance V5.01 admin Disk Usage: 4%				Motion D	Detection is on Email Alarm is on	Script-Stream	
Crivis	Start Menu		Quickstart	Recordings	System Administration		System Status	Logout
and you see more!	Cam 1 Cam	2 Cam 3						
	The Remote Acce	ss has been a	activated!					
	Deactivate Remote A	ccess	figure Remote Access					
	Start Page							

If the data was entered correctly, the remote access is now active and the function can be tested by calling

Note

If you can't log in as expected, it might be possible the wrong port is specified in web address. In this case you try to log into the wrong C-MOR and the password will not work. If no port number is displayed in the configuration the server, username or password has an error. Please verify the data in this case.

the address <u>http://remote.c-mor.com:1xxxxxx</u>. The password prompt from your C-MOR will appear. Please notice also, that the remote access data can be used on one C-MOR only and does not work on more than one device at the same time.

Please call the remote access configuration again to verify the data:



Remote Ac	cess Configuration		open/close		
This configuration	on menu performs the remote acco	ess configuration.			
Internet Remote Access is active.					
Deactivate Remote Access					
HTTPS Transfe	r 🗌				
Server	remote.c-mor.com				
Port	0 (automatically assigned)				
Username	cmorremote				
Password	•••••				
Save Configu	ration				
To get remote a	ccess via the Internet to your C-M	OR you must first register a paid subscription. This registration is available at www.c-mor.com			

If the remote access is set up you can reach your C-MOR via an address like https://remote.c-mor.com:64444. The so-called port number (example 64444) is always reserved and awarded for you individually!

Click on "Deactivate Remote Access" if you want to disable the remote access:

The Remote Access has b	boon deactivated			
The Remote Access has been deactivated!				
Activate Remote Access	Configure Remote Access			
Start Page				

3.1.20.1 Remote Access Limitations

C-MOR remote access only enables users to access the C-MOR self. The direct access to connected IP cameras is not possible since the remote access is limited to one TCP-IP port. Each direct camera access (the camera web interface) requires an extra TCP-IP port. C-MOR offers extended remote access configurations to access also the cameras. Please contact C-MOR directly if this is required.

3.1.21 Stacking function - interconnecting several C-MOR units*

By "stacking" in the technical area, the interconnection of individual, standalone units is understood to be a common, central management unit. The C-MOR Stacking is an interconnection of the configuration level. A separate, physical separate network connection is necessary only for large stacking configurations.

The stacking function of C-MOR allows the interconnection of up to 6 C-MOR units over one single management interface. This stacking works with virtually installed C-MOR video surveillance systems, too.

With a central master unit it is possible to include 5 more C-MOR units and manage them centrally. Overall it is possible to manage and record 90 cameras with one Interface.

3.1.21.1 Stacking configuration of the C-MOR Master

First install the stacking master software update prior configuring C-MOR stacking. The master functionality is available as a separate update. After the successful installation the C-MOR Stacking configuration shows up in the "System Administration" menu:

Stacking Master Configuration

This configuration menu performs the stacking master configuration.

Stacking Master Configuration

Additional C-MOR units are entered and activated in this configuration menu. Up to 5 other devices are configurable. In the fields for the IP addresses or DNS names, enter the additional C-MOR devices and set the hook for "Active". Optionally set if the individual units are opened in new tabs or windows in a web browser.

Important Note

The C-MOR units must be available over network or Internet.

* Refer information in advance whether this module is released for your version. Or inquire us..

After clicking "Save configuration" all active units are availability on top of the existing menu bar.

	Stacki	ng Configur
tacking coml	bines multiple C-MOR to one u	nit. Multiple C-I
Ű.		1 - C
Stacking	enabled	
Open link	ks to stack units in new tabs or	r windows (refer
Stack Unit	IP address/DNS name	Active
Unit 2	172.20.1.88	
Unit 3	172.20.1.77	
Unit 4	172.20.1.77	
Unit 5	192.168.6.56	
Unit 6	17.20.1.211	
	J.	
Save Co	onfiguration	
Start Page		
otan'i age	2	

If individual units should be removed from the stacking, so only mark the unit not "Active" and the respective unit is removed after saving the new configuration.

3.1.21.2 Stacking configuration of the C-MOR Slaves*

Condition for the stacking feature is that on all the slaves the master C-MOR with login and password are the same. This must be applied to the respective slave unit. The settings are made in the "System Administration". The slave configuration is available in any C-MOR without additional module installation.

Stacking Slave Configuration				
This C-MOR belongs to a stack combination. Set the master C-MOR in the following address field.				
aster C-MOR:				
Save Configuration				

* Refer information in advance whether this module is released for your version. Or inquire us..




3.1.21.3 Stacking Live View function

After the stacking feature is configured and enabled in the user interface, the additional buttons appear at the top. With these buttons, "Unit 1-6", the connected C-MOR is reached. The currently active unit is color coded and the live view is displayed in the active window. Up to 90 cameras are easily accessible with this function over this central administration.

View of the central administration with the buttons to the other units:

C-MOR	IP Video Surveilland V5.01 admin Disk Usage: 1% Start Menu Cam 1 Cam 2 C	ce	Quickstart 5 Cam 6 Cam 7	Recordings Cam 8 Cam 9 Cam 10		ystem Administration Cam 13 Cam 14 Cam 1	15	Motion Detection is on Email Ala Unit 1 Unit 2 Unit 3 System Status	rm is on Script-Stream V Unit 4 Unit 5 Unit 6 Logout
1.	4	2.	2	3.	Ċ	4.	4	5.	
C-MOR	C-MOR	C-MOR	<u> </u>	C-MOR	C-MOR	C-MOR	C-MOR	C-MOR	C-MOR
C-MOR	C-MOR	C-MOR	C-MOR	C-MOR	C-MOR	C-MOR	C-MOR	C-MOR	C-MOR

View of the "Unit 4" after switching from the "Master Unit":



All units can be accessed via an IP address or domain name. The credentials must be entered only once. This allows users to manage individual C-MORs comfortable and convenient.

The stacking master function is not part of the standard delivery of C-MOR. Separate software modules needs to be installed for all master devices separately and must be licensed and appointed.

Note

Please note the following limitations of the stacking capability:

User must be created on each C-MOR unit with the same name and password. The user IDs are not synchronized between master and slave. After a single configuration no other changes for the operation must be observed. Users, for example, will have access only for "Unit 1", but not for "Unit 2".

3.1.22 System Restart



In case of unexpected problems, using this menu item you can restart C-MOR.

System Restart	open/close
By pressing the button "Restart system" the C-MOR system will be restarted on the spot. The Restart process will take approximately 3 minutes!	
System Restart	

3.1.23 System Shutdown

In case you have to switch off C-MOR due to administrative work, please proceed under **System Shutdown**.

System Shutdown	open/close
By pressing the button "Shutdown System" the C-MOR system will be shut down on the spot.	
System Shutdown	



3.1.24 Software- and Camera Updates

The software of C-MOR is constantly being expanded and improved. Known issues will get fixed and the updates will be provided to customers via the internet. Its development depends at some degree on the technology offered by other manufacturers and companies. Manufacturers constantly develop new technologies and well-known standards may change.

When browser manufacturers change an old security technology with a new one. C-MOR developers must also implement this technology into the system. This is important for compliance according to security standards and to sustain proper function of the system. Vice versa a system that's not up to date may lose its functions and refuse to work.

With its updating function C -MOR can simply be brought up to date via internet. It's important to note that only Users with a subscription can perform updates. Feel free to contact our Support-Team with questions regarding subscriptions.

New updates will be displayed under System Status:

Version Display				
System:	C-MOR15-15			
System Name:	C-MOR			
Version:	5.0100, latest available version: 5.0101			
MAC Address:	0c:c4:7a:97:9b:ae			

There are two functions: Software Update and the Camera Update.



Note

After an Update you will be asked to accept the Disclaimer again.



3.1.24.1 Software Updates

This menu offers you the opportunity to bring your software version up to date. First you have to deactivate all of your cameras. Therefore, you will find two possibilities. First you can go to the menu "System Administration". There is a function called:

Maintenance Mode	open/close
Recording Camera1: deactivated Start Recording	
Recording Camera2: deactivated Start Recording	
Recording Camera3: deactivated Start Recording	
The Maintenance Mode is not enabled.	
Activate Maintenance Mode	

Or you navigate directly to "Software Updates" There is also a button which deactivates all of your activated cameras with just one click on "Activate Maintenance Mode".

C-MOR Updater

Please activate the Maintenance Mode in order to install updates!

Activate Maintenance Mode

Please fill out this form to list the availables updates.

Username:	
Password:	
Server name:	update.c-mor-video.com
Directory:	/updates/v5/main/03/c-mor-v5-5.21

Updates are installed without a proxy!

List available updates

If you have deactivated all cameras, you can download the newest updates of C-MOR.



Important Note

C-MOR needs free access to the internet to download and install the updates. For this, C-MOR supports the use of a web proxy or HTTP. Before you update your software you have to check in the "System Administration" the proxy settings are correct. Please make sure which update you import. Depending on the update a specific update sequence must be observed. When the installation has failed, this can lead to failure of C-MOR.

If you have started the software updates, so the update data will be requested from the web interface of C-MOR. Now you have to insert your username and your password from your datasheet (C-MOR Subscription) the name of the server and the directory are given from the system. More information about the updates and functions you can receive from the Support Forum where you have to be registered: https://www.c-mor.com/video-surveillance/forum/

Please fill out this form to list the availables updates.				
Username:	username			
Password:	•••••			
Server name:	update.c-mor-video.com			
Directory:	/updates/v5/main/15/c-mor-v5-5.01			
Updates are installed without a proxy!				
List available updates				

After you click on the button "List available updates", then a list of updates will appear. If there are no updates available, you will be redirected to the following page:

Available C-MOR updates, c-mor-v5, Version 5.0103:					
ID	Version	Description			
No updates for this C-MOR version were found.					
Update aborted!					

But if there are updates available you will redirected on following page:

ID	Version	Beschreibung	
1	5.0101	Update to Version 5.01PL01	
2	5.0101	Update to Version 5.01PL01	
3	5.0101	Update to Version 5.01PL01	
4	5.0101	Update to Version 5.01PL01	
5	5.0101	Update to Version 5.01PL01	
6	5.0101	Update to Version 5.01PL01	
7	5.0101	Update to Version 5.01PL01	
8	5.0101	Update to Version 5.01PL01	
9	5.0101	Update to Version 5.01PL01	
10	5.0101	Update to Version 5.01PL01	

Updates found: 10

The download and installation of the updates may take some minutes time. Do not interrupt the installation process once it was started!

Software	Update	Disclaimer
----------	--------	------------



To install the updates first you have to accept the disclaimer, just put a check mark in the box provided.

After that you can click on the button "Download and install updates now" to start the updates. All affected files are downloaded and installed now. This process may take several minutes to complete. If the update was successful, it is indicated in the following website:

Number of installed updates: 1

The updates have been installed. C-MOR has to be rebooted after each update! Activate the cameras after the restart again.

Restart System

Depending on the type of update C -MOR must be restarted. Whether this is necessary is specified with the update instructions in the C-MOR web, or forum.

Once the update is complete, with or without restart, you have to activate your cameras in the "System Administration" again. Thus, the update process is finished.

C-MOR

System Name	open/close
Network Configuration	open/close
SSL Certificate	open/close
Proxy Server Configuration	open/close
Email Alarm	open/close
Set Time	open/close)
Configuration of the Time Zone	open/close
Time Server	open/close
Maintenance Mode is enabled!	open/close
All cameras are deactivated by the administrator!	
Deactivate Maintenance Mode	

Note

This function just activates that cameras, which were already active before the update.



3.1.24.2 Camera Update

Software Update

With this function you can update your C-MOR. Please select between updating the C-MOR Software and the camera database.

Software Update Camera Update

C-MOR continuously adds new cameras. If your camera model may not be listed in C-MOR, maybe a camera-update will help you. With a camera update the latest camera database is loaded via the internet.

Available C-MOR Camera updates, c-mor-v4, Version 94:

Ι	D	Description
	1	Update camera types 20 -06-23 added various IP Cameras
	3	Update camera version file

Updates found: 2

The download and installation of the updates may take some seconds time. Do not interrupt the installation process once it was started!

Download and install updates now

Just click on the button "Download and install updates now" after that the camera database will be updated. In contrast to the software update, you don't have to deactivate the cameras first.

C-MOR Updates installation

Do not stop the installation and wait until it shows the installation has finished.

1. 94 Update camera types 20 -06-03 added more Tenvis IP Cameras

3. 94 Update camera version file

Number of installed updates: 2

The camera updates have been installed!

Start Page



3.1.25 License Upgrade

License Upgrade

With this function you can activate up to 15 cameras on this C-MOR!

License Upgrade

You can upgrade each C-MOR up to 15 cameras, but you must remember that the processor performance will be affected. The built-in processors are designed in each case for the different C-MOR models.

In order to perform a license upgrade, you will get from us the following information: user name, password, and a license key.

As like the software update, C-MOR needs at this point unrestricted access to the Internet.

License Upgrade
-1 3
6 cams licensed
o cans licensed
Please be careful using this program. It rewrites the license files without any warnings! Make sure C-MOR has free access to the Internet! Activate the C-MOR proxy if
necessary.
Username:
Password:
License Key:
Lienze Unerede
License Upgrade

3.1.26 Backups

C-MOR offers different options to manage camera settings. These options are

- Download and save camera settings on a local computer (PC/Mac)
- Restore camera settings from a local computer
- Transfer camera settings between cameras
- Delete restored (uploaded) camera settings

C-MOR automatically generates up to 5 backup sets per camera. These backups are always generated by saving the camera settings. The oldest set is automatically deleted when the 6th backup set is generated. C-MOR will always hold a maximum of 5 backup sets for each camera.

3.1.26.1 Backup Management

The menu for the backup management can be found on the page "System Administration":

Backups
In this management page backups can be listed, downloaded or uploaded.
Backups

A click on the button "Backups" opens the Backup Management page:

Backups
Available Camera Backups
backup_cam1_2015-05-22-13-11-07.cbkf
backup_cam1_2015-05-11-09-09-26.cbkf Download
backup_cam1_2015-05-11-09-09-13.cbkf
backup_cam1_2015-05-11-09-08-14.cbkf Download
backup_cam1_2015-05-11-09-05-04.cbkf Download
Upload Camera Backup Local Camera Backup File: Durchsuchen_ Keine Datei ausgewählt. Upload (Has to be a CBKF File! Backup file name will be listed as 'upload_FILENAME.cbkf.)
Uploaded Backups Start Page

The Backup Management page exists of 2 parts. The first part lists the automatically generated backups of each camera. Each backup can be downloaded by clicking the "Download" button. The second part includes the function to upload backups manually. Such backups maybe were transferred from another C-MOR.



3.1.26.2 Restore Camera Backups

In order to configure camera settings with a data backup, the data backup must first be loaded onto the C-MOR, if it is not a camera configuration that has already been configured on the same system. The data backup page "backup.pml" can be used to check whether the data backup to be used exists. If the backup is not available, it can be uploaded using the "Upload camera backup" function on the C-MOR. If the data backup or camera configuration you are looking for is present on the C-MOR. It switches to the camera configuration for the import of the data backup. The camera configuration can be found via the system administration or via the camera page. In the configuration page, the function for importing the camera configuration is located at the top of the page below the PTZ configuration:

backup_cam1_2015-05-11-09-05-04.cbkf	✓ Load Backup Data	Backups
--------------------------------------	--------------------	---------

The restore function selects automatically the first available backup. Be aware and do not click "Load Backup Data" if the selected backup is not the one you want to restore. Simply leave the page without saving if you have loaded the backup in error. Click into the backup drop down menu to get a full list of all available backups with name of the camera and the date and the time:

backup_cam1_2015-05-11-09-05-04.cbkf 🗸	Load Backup Data	Backups
backup_cam1_2015-05-11-09-05-04.cbkf		
backup_cam1_2015-05-11-09-08-14.cbkf		
backup_cam1_2015-05-11-09-09-13.cbkf		
backup_cam1_2015-05-11-09-09-26.cbkf		
backup_cam1_2015-05-22-13-11-07.cbkf		

Click on "Load Backup Data" to restore the data from the backup you want to restore. You have now the option to optimize the settings. Click on the button "Save Configuration" to store the restored data permanently.

If the desired Backup-Data is not in this list, you can click on the button "Backups" to upload your desired backup.

Note

Please consider that the camera backup only contains the camera configuration. It does not include PTZ settings nor Time-Tables!



3.1.27 Stream-Type

The video material is transferred by different kind of streaming through the network. These streaming types differ in their method of transmission. Please check out the chapter about the streaming-types if you are experiencing presentation problems or performance issues of the server or client. The streaming-types vary considerably which can have a huge impact for the system.

Under certain conditions it may be required to make some changes at the browser's configuration page.

For each user the display method of the Livestream can be selected. This Setting is depending on the usage over Internet or the local network, or which browser you use

To use the desired Stream-Type, the Administrator can setup the Settings in the **System Administration** -> **User Administration** or the user self, if the user selects the **System Administration** page. The administrator can change this setting for each user as described in this manually.

Configuration of the Live View as C-MOR-Stream or as MJPEG-Stream
Live View as C-MOR-Stream
 Live View as MJPEG-Stream
Save Live View Mode

If the process was successful the following Information should appear:

Live view mode for user admin set to C-MOR-Stream.

With the Button "Start Page" you will be redirected to the Live View on the Start Page.

To swap short-term to another Stream-Type you can use the dropdown Menu on Start Page to choose the desired Mode.

C-MOR	IP Video Surveillance V5.21 admin Disk Usage: 4%						Motion Detection is on Email Alarm is on ✓ C-MOR-Stream MJPEG-Stream				
0-11013	Start Menu 🔛		Quic	Quickstart Recordings		ngs	System Administration	System Status	Logout		
and you see more!	Cam 1	Cam 2	Cam 3	Cam 4	Cam 5	Cam 6					

3.1.27.1 C-MOR-Stream:

C-MOR-Streaming works its way through all firewalls and proxys. C-MOR takes use of the push-method and sends the data. Here C-MOR must get active and raises CPU usage. However, this method works in the majority of cases.

3.1.27.2 MJPEG-Stream

This kind of streaming stresses more the client. Because the client needs to grab the video data from the server. He doesn't get it delivered. This means less load on the C-MOR server. Performance of the live-



streams is generally increased. At the downside Googles Chrome only supports 6 cameras with this kind of streaming. Microsofts Internet Explorer isn't supported.

Mozilla's Firefox does support 6 cameras but with some tweaking then supports up to 15 cameras.

Important Note

All changes that you make to your browser you do at your own risk!

To tweak Firefox please enter about:config into the URL-bar. You have to accept the upcoming disclaimer about warranty claims.

about:config × +	×
← € Firefox about:config ▼ C	≡
This might void your warranty! Changing these advanced settings can be harmful to the stability, security, and performance of this application. You should only continue if you are sure of what you are doing. I'll be careful, I promise!	

Type *persist* into the search-field:



about:config × +							
Firefox about:config		C Q	Search	 ☆│自	Ŧ	Â	Ξ
Sea <u>r</u> ch: persist							×
Preference Name	Status	Туре	Value				E,
devtools.webconsole.persistlog	Standard	boolean	false				
network.http.max-persistent-connections-per-proxy	Standard	integer	32				
	Standard	integer	6				
network.http.max-persistent-connections-per-server							
network.http.max-persistent-connections-per-server network.http.spdy.persistent-settings	Standard	boolean	false				

Now choose *network.http.max-persistent-connections-per-server* and change the value from 6 to 15. After that click OK

about:config × +						-	- □	×
Firefox about:config		C	Q Search	☆ [à ↓	Â	◙	≡
Sea <u>r</u> ch: persist								×
Preference Name	▲ Status	Туре	Value					E.
devtools.webconsole.persistlog	Standard	boolean	false					
network.http.max-persistent-connections-per-proxy	Standard	integer	32					
network.http.max-persistent-connections-per-server	Standard	integer	6					
network.http.spdy.persistent-settings	Standard	boolean	false					
plugin.persistentPermissionAlways.intervalInDays	Standard	integer	90					
2	15 ОК З	Can	cel					

Firefox can now handle 15 Camera-Streams.



3.2 Camera Configuration

3.2.1 General Description of Configuration Options

In order to configure a camera the following settings can be carried out:

- Define description of the camera's location
- Activate / deactivate recordings
- PTZ-Configuration
- Define storage time of recordings
- Define camera network data
- Configuration of camera type (Axis, Mobotix, Panasonic, Sony, etc.)
- Image Size

Optionally the image size should be set if the values are known.

Threshold for motion detection

This function increases or decreases the sensitivity threshold to activate motion detection.

• Fast Motion Permanent Recording

Besides motion detection it is possible to create a permanent recording. This mode generates a movie with images that are recorded in the given interval.

This interval shows when a picture is taken. If you want a real-time recording, set for example the interval to "1 second". This means that every second a new image is recorded.

ast Motion			
Permanent	1 Second	٠	
Recording	1 Second	*	
	Off		
	1 Second		
	2 Seconds		
	3 Seconds		
	4 Seconds		
	5 Seconds		
	6 Seconds		
	7 Seconds		
	8 Seconds		
	9 Seconds		
	10 Seconds		
	15 Seconds		
	20 Seconds		
	30 Seconds		
	45 Seconds		
	60 Seconds		
	2 Minutes		
	3 Minutes		
	4 Minutes	-	
	· · · · · · · · · · · · · · · · · · ·		



Recording length of time-lapse recordings

This parameter defines the length in time after a new recording will be started for time-lapse recordings. If set to Hourly each hour a new recording will be generated.

• Enable JPEG images in motion detection mode

In motion detection mode the recording is in MPEG format. This feature enables JPEG images to be generated as well. These images can be easily saved as a ZIP archive.

• Enable JPEG images in scheduled recording mode

In scheduled recording mode the recording is in MPEG format. This feature enables JPEG images to be generated as well. These images can be easily saved as ZIP archive.

• Scheduled recording mode - JPEG image intervals

When the feature generating JPEG images is enabled, this function sets the time interval between when each JPEG image is generated.

• Number of images Pre-Event

In motion or event detection mode, sets the number of frames recorded pre-event.

• Number of images Post-Event

In motion or event detection mode, sets the number of frames recorded post-event.

• Frames per second (fps) in motion detection mode

This defines the number of images per second during the recording with motion detection. Please select this parameter carefully. The interval can be set between 1 frame every 3 seconds up to 25 frames per second. You must be careful how high the maximum number of frames per second can be supplied by the camera. If the camera can supply up to 5 frames per second, then C-MOR isn't able to record in a higher interval.

Please keep in mind that a too high number of frames with a very high resolution can overload the system.

• Rotation of Image

The cam can be installed at an angle of 0, 90, 180 or 270 degrees and this function allows the orientation of the viewed image to be rotated for normal viewing. A 180 degrees recording makes e.g. sense in case the cam is installed on the ceiling down sided.

• Maximum Time of recording for Motion Detection

Sets a limit to how long recording takes place in Motion or Event Detection mode irrespective of whether the event that triggered the recording still exists or not.



Recording Mode

The recording mode switches between motion detection and permanent recording (not time-lapse). When the permanent recording mode is activated, motion is no longer detected and not individually recorded (no more alarming is possible!). The duration of the recordings have the length which is set for motion detection.

• Display Frame around changed Pixels

This parameter defines whether a frame will be displayed around changed pixels. This is very helpful in case the threshold for the motion detection for the cam image is defined.



Motion detection with frame

• Display the Number of changing Pixels

This feature shows the number of changing pixels in the top right corner of the video. This parameter is very useful when optimizing motion detection parameters.



Motion detection with number of changed pixels

• **Display Text with time and date in cam image** Feature for the activation and deactivation of the display of time and date in the cam image.



Note

Emails are only generated when Email-Alarm is activated here.

Automatic email alarm during Motion Detection

Feature for the activation and deactivation of the email alarm in case motion has been detected by the cam. A plain text email will be sent (excluding image or movie attachment).

• Email address for alarm emails

This is the email address alarm mails are sent to.

Please note: in case of a lot of motion and many recordings that are effected during motion detection your mailbox might reach its storage limit very fast and cannot receive emails anymore!

• Attach Motion Detection recordings to alarm email

This feature enables video images to be attached to the event email alert.

• Mobile device compatible Email attachments

Enable this feature if email attachments are sent to a mobile device.

Direct Cam Link

Network Cams might be linked directly over C-MOR. This setting is needed when network cameras are not located at the same location and are only accessible behind a router through the internet.

• Text on left side in cam picture

This optional text will show up in the left lower corner of the camera picture. If this field is empty no text will be shown.

• Show picture text in double size

The text in the camera picture can be shown in double size. This is useful for big pictures or special usage of the pictures.

Web camera picture quality

This value defines the video quality in percent for the data transfer of the camera picture to C-MOR. The default value is 50%. Changing this parameter may cause a high system load which can cause system failures.

Note

This affects only the display. The video will still be recorded in full quality



• JPEG image quality

This setting defines the quality of the JPEG images stored on C-MOR. The default value is 100% - highest quality.

• Time between two events

Time in seconds without motion after a new motion movie is recorded.

Automatic camera image quality (bitrate)

This feature automatically adjusts the quality of the image transferred from the video camera to C-MOR. A value of 2 represents the highest image quality and requires the most storage capacity. Higher values reduce data storage capacity requirements by decreasing the image quality.

• Manual bitrate for recordings

This feature manually sets the quality of the image transferred from the video camera to C-MOR manually. A value of 9999999 represents the highest image quality and requires the most storage capacity and bandwidth. Lower values reduce data storage capacity requirements by decreasing the image quality. This value should not set lower than 200000. This value is only active if the automatic value above is switched off (value 0).

If your image is recorded distorted in the lower area, this may be due to the bit rate. Correct the value Bitrate of the image transmission from the camera from 2 to 0. Then set the value of the manual bit rate to 8 000 000. If the distorted strip increases reduce the manual bit rate. If it is smaller, increase the value to a maximum of 9 999 999.

You may have to experiment with different values until the bottom area is displayed correctly.

• Minimum number of pictures with changes for Motion Detection

The number of pictures with changes to detect motion. The value 1 is capable in the most cases. This means only one picture is compared to detect motion.

• Sudden light intensity

This feature defines the percentage of the total video image area that has to experience a sudden light intensity change before triggering a recording event.

Number of ignored Lightswitch Frames

The number of frames in sudden light indicates how many camera frames should be ignored in serial not triggering motion detection. This value is ignored if sudden light intensity is set to 0%.

Noise

Noise in the camera picture can lead to erroneous motion detection. With this parameter failures in motion detection are reduced.



• Live view – fps

This setting configures the fps rate in live view mode. The higher the frame ratethe higher the internet bandwidth requirement. This setting does not affect the fps rate in motion/event or permanent recording mode.

• Use keep-alive signal for the camera connection

This parameter forces C-MOR to use a keep-alive technology to communicate with the camera. If the parameter 'force' is selected an existing socket connection will be re-used if this feature is supported by the camera. This setting is also necessary for compatibility with various IP cameras.

• Number of Frames per Second in Live view

This setting configures the fps rate in live view mode. The higher the fps rate the higher the internet bandwidth requirement. This setting does not affect the fps rate in motion/event or permanent recording mode.

• Use TCP when selected RTSP connection

This parameter configures whether the communication to the camera takes place with TCP instead of UDP if the stream protocol 'RTSP' was selected.

• Reduce stream speed in C-MOR Web Interface

This parameter lowers the stream speed in the C-MOR Web Interface while no motion is detected to 1 frame per second. This parameter is very effective when using the preview or downloading video recordings. Once motion is detected the stream is accelerated to the set value.

• Time-controlled recordings

Setting of hour and day per week when recordings have to be carried out. This applies e.g. when recordings should only be carried out during nighttime at a store.

Time controlled recordings

The selected hours 0-23 display, when the recording on the individual weekdays takes place according to the selection:

Time (Hour)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Holidays	✓	-	✓	✓	✓	✓	✓	✓	•	•	✓	•	✓	✓	✓	✓	•	✓	✓	✓	✓	✓	•	•
Monday	✓	✓	✓	✓	✓	✓	✓	✓	✓	•	✓	✓	✓	✓	✓	✓	•	✓	✓	✓	✓	✓	•	•
Tuesday	•	✓	•	✓	✓	✓	•	✓	•	•	•	✓	✓	✓	✓	✓	•	✓	•	•	•	•	-	-
Wednesday	•	•	•	✓	✓	✓	✓	✓	•	•	•	•	✓	•	✓	✓	•	✓	•	•	•	•	-	•
Thursday	•	•	•	•	•	•	•	•	•	-	•	•	•	•	•	•	•	•	•	•	•	•	-	-
Friday	•	-	-	•	✓	✓	•	•	•	-	•	-	•	•	✓	✓	-	•	•	•	•	•	-	-
Saturday	-	•	-	~	~	•	•	•	•	-	-	•	-	•	•	•	-	•	•	-	-	-	-	-
Sunday	-	•	-	-	-	-	-	-	•	-	-	•	-	-	-	-	-	-	-	-	-	-	-	~
Save Time	Re	cor	ding	J	l	Jns	ele	ct al	I		Sele	ecta	all											
Time Table	Em	ail A	\lari	m C	am	era	1		┙[Lo	ad	Tim	e T	able	е									



• Time-controlled motion detection

Definition of hour and day per week motion detection should be carried out.

• Time-controlled alarm emails

Define weekdays and hours in which alarm emails are sent.

• Transfer of timescale

Every timescale, even if time-controlled motion detection or time-controlled alarm emails is able to transfer to another timescale. Therefore you have to choose a timescale and commit your selection with "Load Time Table":

Time Table Motion Detection Camera1	\mathbf{v}	Load Time Table

If you want for example your camera 3 with the same settings like your camera 1, so you have first go to the configure site for your cam 3.

Recording by motion detecting and time

The selected hours 0-23 display, when the recording by motion detection on the individual weekdays takes place according to the selection:

Time																								
(Hour)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Holidays	•	~	•	•	•	•	•	~	•	•	•	•	•	•	•	•	•	-	•	•	•	•	•	~
Monday	•	•	•	-	-	•	•	•	•	•	~	•	•	•	✓	•	•	•	~	•	~	•		•
Tuesday	•	-	•	-	-	•	•	-	-	•	-	•	•	•	•	-	•	-	-	•	•	-	✓	-
Wednesday	-	-	•	-	-	-	-	-	-	•	-	-	•	-	•	-	•	-	-	-	-	-	•	-
Thursday	•	-	•	-	-	-	-	-	-	•	-	>	•	-	✓	-	-	-	-	-	-	-	✓	-
Friday	-	-	•	-	-	•	-	-	-	•	-	-	•	-	-	-	•	-	-	-	-	-	-	-
Saturday	•	-	-	~	-	•	-	-	-	•	-	-	•	-	-	-	-	-	-	~	-	-	•	-
Sunday	•	-	~	-	~	~	~	-	-	-	-	-	~	~	-	-	-	-	-	~	~	~	-	-
Save Motion D Time Table Time Table Time Table	Em Em	ail A ail A	lan	m C m C	am am	era	1		v	_	_	elect]										
Time Table Time Table Time Table Time Table	Em	ail A	lar	m C	am	era	3	a1																

With help of the drop-down menu you can choose the timescale you want. For example choose the "Time Table Motion Detection Camera 1":

Time Table Motion Detection Camera1 👻 Load Time Table



Now you have to confirm your selection by clicking in "Load Time Table", you can see that the settings are transferred:

Recording by motion detecting and time

The selected hours 0-23 display, when the recording by motion detection on the individual weekdays takes place according to the selection:

Time (Hour)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Holidays					✓	✓	✓	✓	✓	•	✓	✓	✓	✓	•	✓	✓							
Monday					✓	✓	✓	✓	✓	•	✓	✓	✓	✓	•	✓	✓							
Tuesday					✓	✓	◄	◄	✓	✓	✓	✓	✓	✓	✓	✓	✓							
Wednesday					•	✓	✓	•	✓	•	•	✓	•	•	•	✓	•							
Thursday					✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓							
Friday					•	•	•	•	✓	•	•	•	•	•	•	✓	•							
Saturday					✓	✓	✓	✓	~	✓	✓	✓	✓	•	•	✓	✓							
Sunday					•	~	~	~	-	•	~	~	~	~	-	-	~							
Save Motion D								nsele				elect		2										
Time Table	Em	ail A	\lar	m C	am	era	1		<u> </u>	Loa	d Tin	ne Ta	able	J										

Now you have to click on the button "Save Motion Detected Time Recording" to save it:

Time table for recordings by motion detection of cam 1.

Recordings are running only at the selected times.

Time (Hour)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Holidays			\square																		\square	\square		
Monday			Γ															\square			Γ	\square		
Tuesday																								
Wednesday			Γ															\square			\square	\square		
Thursday																								
Friday																								
Saturday																								
Sunday			Γ																		\square			

Hinweis

Since version 4.01 of C-MOR, you have additional switching functions for "Motion Detection" and "Email Alarm". On the C-MOR interface you see them top right if the user is logged in as administrator:

C-MOR	IP Video						Motion Detection i	s on Email Alarm is on C-MO	R-Stream
C-MOR	Start M	lenu 🗮	Quic	kstart	Recordin	ngs	System Administration	System Status	Logout
and you see more!	Cam 1	Cam 2	Cam 3	Cam 4	Cam 5	Cam 6			

With these buttons the administrator is able to deactivate "Motion Detection" and "Email Alarm". So, the Time Tables for motion detection or email alarm can also be switched off. These buttons you also have on the iPhone or mobile interface of C-MOR.



• Holidays Configuration

C-MOR offers the option to define holidays. Holidays are days which need a special time table configuration. All time tables have a row holidays. These holidays are configured here. C-MOR will not use the weekday configuration if the current day is a defined holiday.

Holidays Configuration

2014-02-29	
2014-06-15	
(One day each line. Date format	t: YYYY-MM-DD, e. g. 2012-04-30)
Sava Halidaya	
Save Holidays	

• Configuration of camera event for network alarms

Recordings by C-MOR can be triggered by the use of external switches (special accessories) that report events over your network. Here it is necessary to use an IP switch, which is sending messages to C-MOR via the so-called syslog service. This will then start a recording for the selected camera.

• Image mask for the definition of the area of motion detection

In case motion should not be detected within the complete camera image the area where motion should be detected (white area) can be defined by a black & white mask. The defined black area will not trigger motion detection. The size of the image mask has to be identical to the size of the camera image.

Link to the camera direct access

The button "Cam Administration" leeds you to the web interface of the selected camera.

General Information about motion detection:

Motion detection carried out by C-MOR is based on differences in the respective camera image and not due to conventional motion detectors (exception: special accessory external switch). Motion detection can also be effected by changes in light.



3.2.2 Camera Activation

Under "Maintenance Mode" it is possible to control the activities of the individual cameras and start or stop recordings. In case the recording of a camera is deactivated there will not be any saved video recordings of this camera. Depending on the camera configuration in case of an activated camera, permanent recordings and/or motion detection is saved in individual files.

Maintenance Mode	open/close
Recording Camera1: deactivated Start Recording	
Recording Camera2: deactivated Start Recording	
Recording Camera3: deactivated Start Recording	
The Maintenance Mode is not enabled. Activate Maintenance Mode	

You can activate or deactivate the camera directly in the respective camera configuration:

			Camer	a Config	guration Camera 1
Cam Location:					Change Location
Recording cam 1: a	activated Stop F	Recording]		
Camera PTZ Con	figuration				
backup_cam1_201	5-05-11-09-08-1	4.cbkf 💙	Load Bac	kup Data	Backups
Delete the Recordir	ngs after 10 🕚	days	Save		
Camera Netwo	rk Data				
IP Address/DNS N	ame 172.20.1	.137			
TCP-IP-Port	80				
User Name	viewer				
Password	•••••	•			

3.2.3 Camera Configuration, Integration of Existing Camera

If you have a camera that's already supported by C-MOR, you can directly enter the IP and port number, the username and password. Therefore you may have set up this information in your camera.

In the menu item Adjust Camera Configuration you can define further settings for the individual cameras.

Under **Network Data** the following data is displayed: the current IP address of the camera, the TCP port, the user name and the password with which C-MOR is accessing the camera with.

Camera Network Data

IP Address/DNS Name	172.20.1.137
TCP-IP-Port	80
User Name	admin
Password	••••

3.2.4 Camera Type

The next section deals with the type of camera. You can select the camera type of the list. Use the search field in the first row to search for the camera model. If it is not listed you can configure it manually with the input field *manual path*. IP-Cameras generally offer different kinds of transmission-protocols to be used for streaming. Therefore, choose what should be used depending on camera type whether RTSP, HTTP, FTP or MJPEG should be used. The most cameras work with HTTP as well as RTSP.

Camera Type Configuration

Please select the cam type that matches the connected cam:

Cam Type	Q Levelon
	LevelOne FCS-0010 MJPEG
	LevelOne FCS-0020 MJPEG
	LevelOne FCS-0030 MJPEG on Stream 2
	LevelOne FCS-0030 RTSP (MPEG4/H.264/MJPEG) on Stream 1
	LevelOne FCS-0030 RTSP (MPEG4/H.264/MJPEG) on Stream 2
	LevelOne FCS-0032 JPEG
	LevelOne FCS-0032 MJPEG
	LevelOne FCS-0032 RTSP (Port 7070)
	LevelOne FCS-1010 JPEG
	LevelOne FCS-1040 JPEG
	LevelOne FCS-1041 MJPEG
	LevelOne FCS-1070 JPEG
	LevelOne FCS-1081 MJPEG LevelOne FCS-1091 MJPEG
	Levelone FCS-1091 MJPEG
	Levelone FCS-1151 MJPEG
Protocol	http:// 🗘
Manual path	/channel2

Save Configuration



Note

When you change any data in this section you also have to change it on the individual camera with its own configuration program or over the web interface of the camera. Otherwise C-MOR is no longer able to access the camera and thus no longer able to record.

In case you already have a camera that is supported by C-MOR, you can integrate it by entering the IP address, the port, the user name and the password of your camera. The same settings have to be done for the camera itself.

Under "Configuration Camera Type" you can select the camera type that is most suitable for your camera. C-MOR currently supports all cameras with the standard JPG and MJPG. A complete list of supported IP-Cameras including many more models can be viewed under <u>http://www.c-mor.com</u>. In case you cannot find your model in the list you can request the support of your model either by email or telephone. We will then give you all the details you need.

3.2.5 Manual configuration of a camera

In case your camera is not listed but supported it can easily be connected under the item "Manual Path" in C-MOR. Just enter the directory of the URL of the camera's live image or the camera's MJPEG live stream.

Note

Information regarding the URL's of the streams of your camera will be available at the camera's configuration page directly on the camera. You can also look for information at the camera manufacturer's homepage or at the manual. You can also feel free to contact the C-MOR support regarding this topic.

To integrate a camera into C-MOR you have to supply the URL of the camera's live picture. Or enter its MJPEG-Live-Stream e.g.:

Camera Type Configuration

Please select the cam type that matches the connected cam:

Cam Type	Q Search													
	Y-Cam Bullet HD 1040 RTSP* Y-Cam Bullet HD 1080 RTSP* Y-Cam Bullet HD 720 RTSP* Y-Cam Cube 1080p RTSP* Y-Cam Cube 1080 RTSP* Y-Cam Cube HD 1080 RTSP* Zonet ZVC-7610W Zonet ZVC-7611 Zonet ZVC-7630W Zonet ZVC-7640 Zosi 720P RTSP													
	Zosi 721 RTSP Zosi 1080P Zosi 1080P RTSP Manual Path Not set													
Protocol	http://													
Manual path	/video2.mjpg													



After that, single camera options such as image rotation or maximum recording time can be defined. The description of each setting can be found next to the respective option in the table.

On the same configuration page you are able to plan time-controlled recordings. Please click time and day when you would like to start the video surveillance.

Time controlled recordings

The selected hours 0-23 display, when the recording on the individual weekdays takes place according to the selection:

Time (Hour)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Holidays		✓		✓	✓												•	✓	✓	•				
Monday	✓	✓	•	✓	✓	•	◄	☑	☑	☑	☑	•	•	•	☑	☑	•	•	•	✓	•			☑
Tuesday	•	✓	•	✓	✓		◄					•	•	•			•	•	•	◄				•
Wednesday	•	•	•	•	•	•	✓	•	•	•	•	•	•	•	•	•	•	•	✓	•	•	•	•	•
Thursday	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	~	•	•	•	•	•
Friday	•	•	•	•	•	•	-	-	-	-	-	•	•	•	-	-	•	•	•	•	-	-	-	•
Saturday	•	•	•	•	•	•	-	•	•	•	•	•	•	•	•	•	•	•	~	•	•	•	•	•
Sunday	•	-	•	-	-	•	-	•	•	•	•	•	•	•	•	•	-	-	-	-	•	-	•	•
	Save Time Recording Unselect all										d Tin	ne Ta		lect a	all)									

Please carry out the settings in the table below for "Time Controlled Recording during Motion Detection" just as described above.

The third table defines the times in which alarm emails are sent. The configuration works again as described above. Please configure n the long configuration table if time based alarm emails are sent in general and if recordings are attached to emails. The email address is configured in this section as well.

Recordings can be started by external events (door switches, ultrasonic motion detectors, bell switches and many more). This requires a network switch, like e.g. Barionet or other Syslog-IP switches, to send a system message to C-MOR. The message has to be in accordance with the line defined in this section, which will then trigger the recording.

Cam Syslog Event	
Save Event	

3.2.6 Protocol

For proper communication between C-MOR and the camera both need to use the same protocol for communication. Choose, depending on the camera type, RTSP, HTTP, HTTPS, FTP or MJPEG for transmission. This setting is depending on what is supported by the connected camera. The most cameras wok with HTTP or RTSP.

Please check to enter the correct port. This value can change after you set a protocol and should be checked. Enter the value your camera specifies. Information regarding this can be found at the configuration pages of your camera or can be found in the manual.

The standard ports are:



Protocol	Port
НТТР	80 oder 8080
HTTPS	443
RTSP	554
FTP	21
MJPEG	8008

Note

This data must agree according to the values which were set with the camera specific configuration utility or with the web interface. Otherwise the camera won't be accessible for C-MOR for recording.

3.2.7 E-Mail-Alarm by Motion-Detection

C-MOR can be configured that several events trigger an E-mail-Alarm. For Example if motion is detected, or a camera-failure or by external sensors.

Triggering by external sensors or peripheral devices must be unlocked by us. External sensors may send a message through syslog-IP-trigger to C-MOR and tell him to begin recording. Likewise they can tell him to initiate an Email-Alarm. More information regarding the configuration of C-MOR to work with external sensors can be obtained by contacting us.

An E-Mail sent from C-MOR contains as subject the corresponding camera name, time and the reason. The content holds the essential. The name of the system in question, the reason, which camera is affected or recorded motion detection triggering material and the time. Motion detection triggered alarm events offer the possibility to attach a short video-clip of the alarm triggering event. For this it must be activated:

Automatic Email alert in Motion or Event Detection mode	⊖ on	This feature enables a plain text email to be transmitted when an event trigger occurs in motion or event detection mode. No image attachments are sent with the email.
Email address for event alarms		Enter the email address to which event alerts will be sent.
Attach video images to email event alerts	● on ○ off	This feature enables video images to be attached to the event email alert. This parameter can only be set in combination with an email address and enabled email alert!
Mobile device compatible Email attachments		Enable this feature if email attachments are sent to a mobile device.

C-MOR Video Surveillance





A sample Email: Triggered by motion detection with a short video clip

с-ма	DR : Cam 1 Server is not available
C-MOR Serverpark: Attent	on! The cam 1 Front is not available!

Sample Email: Message subjection camera failure



3.2.7.1 E-Mail Alarm: Configuration

On the configuration page you can enter an e-mail address where messages will be sent to when motion detection occurs.

Note

Attention: With a lot of movement and thus many records, your mailbox can quickly reach the memory limit!

Automatic Email alert in Motion or Event Detection mode		This feature enables a plain text email to be transmitted when an event trigger occurs in motion or event detection mode. No image attachments are sent with the email.
Email address for event alarms		Enter the email address to which event alerts will be sent.
Attach video images to email event alerts	⊖ on ● -#	This feature enables video images to be attached to the event email alert. This parameter can only be set in combination with an email address and enabled email alert!
Mobile device compatible Email attachments		Enable this feature if email attachments are sent to a mobile device.

3.2.7.2 E-Mail Alarm by Motion-Detection – Time-Based

You can specify exactly on which days and at what time you want to receive emails about events. In the lower part of the camera configuration page there are 3 different tables.

The first table *"Time controlled recordings*" defines the times at which the camera is activated in C-MOR. The second table *"Recording by motion detecting and time*" defines the times in which C-MOR stores recordings by motion detection.

The third table *"Alarm Emails by Motion Detection and Time*" concerns the item E-Mail Alarm. Here you can specify the periods for which, in addition to the recordings for motion detection, additional emails are sent as an alarm. This is where the specifications in the configuration table apply.

In all tables, the periods can be entered per day and hour, in addition, all tables contain a row for periods that were defined as holidays, which may differ from the normal time table.



Alarm Emails by Motion Detection and Time

The selected hours 0-23 display, when alarm emails by motion detection on the individual weekdays are sent according to the selection:

Time (Hour)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Holidays	☑	✓	☑					✓			✓	☑		✓		☑	✓	✓		☑			✓	✓
Monday	✓	✓	◄		✓			✓	✓		✓	✓	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓
Tuesday	•	•	✓		•	✓	•	•	•	•	•	✓	✓	•	✓	✓	•	•	•	✓	✓	•	•	✓
Wednesday	•	•	•		•			•	•		•	✓	•	•	•	•	•	•		•	•	•	•	✓
Thursday	•	•	•		•			•	•		•	•	•	•	•	•	•	•		•	•	•	•	✓
Friday	•	•	•		•	•		•	•		•	•	•	•	•	•	•	•		•	•	•	•	•
Saturday	•	•	•		•	•		•	•	•	-	•	•	-	•	•	•	•	•	•	•	•	•	✓
Sunday	-	•	•	-	-	-	-	•	-	-	•	-	-	-	-	-	-	-	-	-	-	-	-	•
	Sunday I <td></td>																							



3.2.8 Image Mask for the Definition of the Areas for Motion Detection


C-MOR reacts on motion in the complete camera image. This might require some kind of limitation so that not every kind of motion leads to motion detection. An example of this would be cars driving by or pedestrians at the property lines. By using this function a black & white mask can be loaded. By the help of this mask C-MOR will only carry out motion detection in the respective white areas.

3.2.8.1 Creating an image mask with Microsoft Paint

The black & white mask can be created as follows: please start with creating a white image of the size of your camera resolution. Please add black layers to those areas where no motion detection should be effected. Then save the image as a JPG file and upload it to C-MOR. All black areas will then be ignored in terms of motion detection.

The following pages describe the steps to create such a mask with your Windows computer.

The creation of a mask works simple and quick and can be done by using the Windows Paint Program.






Please proceed as follows to create a mask:

Save the image of the camera for which you want to create a mask on your computer. Do this by calling the "Quickstart" page. Make sure the stream type on top right is set to "Script-Stream" and select the live view with the highest resolution for the selected camera. In this example we create a mask for camera 1 and the resolution is 640x480 pixels. A new window will open.




The new opened window: Move your mouse pointer over the live view and click the right mouse button. Select "Save picture as…" from the opened context menu.




Please determine in the opened window a filename, such as "livepicture.jpg" and remember the position where the picture has been saved on the hard disk. In the next step the image has to be loaded into Windows Paint Program.


The menu of the Windows Paint can be opened on the top left by a button.



Click on "Open". The following window allows opening the file, which just has been saved.



The picture of the camera is now loaded in Windows Paint.






The loaded picture will now be re-painted with black and white areas. White areas are for motion detection areas. Black areas are not motion-sensitive. It is ideal to paint the black areas first. Please note, that on the top of the menu you lodged the colors "Color 1" and "Color 2" as black color. The second color is the fill color, for example circle, rectangle etc., which is activated as "solid color" at "Fill".



Paint the black areas first (no motion detection):



Now please change both colours to white.



Afterwards the white areas will be painted (area for motion detection):

File Home					livepicture - Paint	- D ×
		A A Brusher Tools		Size	Caluar Ca	^ U
				D		
		a				
	12	10 640	× 480px 🔛 Size: 31.6KB			00% @ +
÷-	100	-12 Dec	A HOUPS 000 SIZE 31.048			wa 🕘 — 🕖 🕘

If the mask is ready, it will be saved locally on the computer. Please open the menu left on top. Then click on "Save as" and choose "JPEG picture".



Please choose a file name. Be careful! If the name would not be changed, the existing name will be maintained and the saved live picture will be overwritten.

🧭 Save As				23	
	illi Berger 🕨 Downloads 🕨 mask	✓ Searce	ch mask	Q	7
Organize 🔻 Ne	w folder			:= • 🔞	
☆ Favorites	A Name	Date modified	Туре	Size	2
Desktop Downloads		No items match your search.			
☐ Libraries ☐ Documents ▲ Music					
E Pictures					
輚 Homegroup	▼	III			•
File name:	mask-camera1.jpg			•]
Save as type:	JPEG (*.jpg;*.jpeg;*.jpe;*.jfif)			•	
) Hide Folders		S	ave	Cancel	.4

Please remember where you saved the mask.

Next, the mask has to be uploaded on C-MOR. Please switch to the camera configuration menu of the camera for which to limit the motion detection. In the example this is "Camera 1". Please select the "System Administration" page on your C-MOR web. Scroll down to "Camera Configuration" and select "Camera 1".



The menu for the camera management opens now. Scroll down to area "Picture Mask for...":

Picture Mask for the Definition of the Picture area in which Motion Detection is active
Mask is not available. Last snapshot: Camera is not active. No current camera live picture available.
Load Mask File: Select Mask Load File
Mask active: no. Motion detection within the whole picture is enabled.
Activate Mask Deactivate Mask Delete Mask



The just created mask has to be chosen and has to be uploaded. Click on "Browse" and select the just created mask in the window that has opened:

6		Choose File to Upload				×		
🔄 🕣 👻 🕆 🛄 > Willi Berger > Downloads > Mask 🛛 🗸 Search Mask 🖉								
Organise 🔻 New folde	er				!≡ ▼ 🔲	0		
4 🚖 Favourites	Name	Date modified	Туре	Size				
E Desktop	livepicture	04/10/2013 12:45	JPG File	32 KB				
🚺 Downloads	mask-camera	04/10/2013 13:01	JPG File	8 KB				
📃 Recent places								
. 🗪								
▲ □ Libraries ▶ □ Documents								
Documents Documents Documents								
Pictures								
Videos								
🛛 🌉 Computer								
•								
🛛 📬 Network								
File n	ame: mask-camera			✓ All Files (*.*)	~		
				Open	Cance	4		
				Open	Cance			

Click on "load File" after the file has been selected:

Picture Mask for	the Definition of th	e Picture area in which Mo	tion Detection is active
Mask is not available. Camera is not active.	. Last snapshot: No current camera live pi	ture available.	
Load Mask File:	Select Mask	Load File	
Mask active: no. Moti	on detection within the wh	ole picture is enabled.	
Activate Mask	Deactivate Mask	Delete Mask	

The file is uploaded to C-MOR. Click now "Activate Mask" to enable the created motion detection mask:

The mask has been up	oaded. Activate the mask to e	nable it.
Activate Mask	Camera Configuration	Start Page

The mask is now activated! Click on "Camera Configuration" to assure the mask is active and is defined for the right motion area:

e mask for motion de	ection of can	nera <mark>1 h</mark> as beer	activated.
Camera Configuration			
Start Page			



The created mask is shown beside the live picture. To the far right the mask is shown in front of the live viewing.

Camera Picture		Mask	Mask on Camera Picture
Load Mask File:s		of the mask. The complete pictu	
Activate Mask	Deactivate Mask	Delete Mask	
Cam Administration	(Settings directly on the	IP Cam)	

Picture Mask for the Definition of the Picture area in which Motion Detection is active

If you would like to correct the mask, simply change the created mask again in Windows Paint on your computer and upload it like you did before.

Important Note:

The black area will also be completely recorded! Only motion will not be recognized. Please refer to your camera manual if you would like to use a privacy mask, a function where the complete area already can be broadcasted blacked out or contact C-MOR directly under <u>www.c-mor.com</u>.

Please note that a mask needs to have the same width and height like the camera image. If the mask has other dimensions, it leads to failure.



3.2.8.2 Create an image mask with http://Pixlr.com

The black & white mask can be created as follows: please start with creating a white image of the size of your camera resolution. Please add black layers to those areas where no motion detection should be effected. Then save the image as a JPG file and upload it to C-MOR. All black areas will then be ignored in terms of motion detection:

Picture Mask for the Definition of the Picture area in which Motion Detection is active

Mask is not available. Last snapshot:



Mask active: no. Motion detection within the whole picture is enabled.

Activate Mask	Deactivate Mask	Delete Mask
Cam Administration	(Settings directly on the	PIP Cam)



To create an image-mask proceed the following steps:

Save the current picture of the camera for which you want a mask to create. For this open the camera configuration page with Mozilla Firefox. At the lower end of the page you will find the last snapshot of the camera. Right-click on the picture and choose *"Save picture as"*. Chose the location where you want to save the picture.

Picture Mask for the Definition of the Picture area in which Motion Detection is active

Mask is not available. Last snapshot:




Mask active: no. Motion detection within the whole picture is enabled.

Activate Mask	Deactivate Mask	Delete Mask
Cam Administration	(Settings directly on the	IP Cam)
Start Page		

After that choose a filename and keep in mind the location where you saved the picture onto your Harddrive.


The next step is to load the picture into a picture manipulation program like MS Paint or in this case <u>https://pixlr.com/editor</u>






Open your Browser and type <u>https://pixlr.com/editor/</u> into the URL field. You will see this image. Now click on "*Open Image from Computer*". Navigate to the place where you saved the snapshot from C-MOR. Open this image.






Now you can paint the picture with white and black areas. White areas will be active areas for motiondetection. Black areas won't be motion sensitive. It is best to first paint all black areas then the white ones.





To make life a little easier, we will first create a second layer at which we will paint.






Now you will select the area which we will fill with black color.

1. Select the Lasso-Tool on the left tool-bar. After you clicked on the Lasso Tool at the left side check out that bar under the menubar. There you can select two different types of the Lasso-Tool. The freehand and the polygonal Lasso Tool. In our case it suits best to use the polygonal lasso tool because we get straight lines with it.

2. Select the area by clicking at the corner points (Polygonal-Lasso-Tool) or freehand draw a border around the area you want to select.

It is not ultimately necessary to select the area first that way before painting it black. But for later steps it will be easier to do it this way and get sharp borders. In a later step we will inverse the selection and therefore get the exact opposite area.






After we draw the border and selected the area:

- 1. Choose the brush
- 2. Select a big size
- 3. Choose black color
- 4. Paint black color into the Area.

You will see, that it is not possible to draw out of the selected area. This is what we wanted. If you notice that some area is missing you can redo the selection-step or paint later with freehand mode with either black or white color onto the layer.






Now the area where motion detection will not be active is black. As next step we have to paint the rest of the image white. For ease of use we did mark that area that is now black. Now we will inverse the selection to get the opposite area which will be painted white.

- 1. Click on "Edit"
- 2. Click on "Inverse Selection"

Now the selection is inversed and ready to be painted.






Check if the brush-tool is still selected. If it is not selected, look for it at in the toolbar at the left side and click on it. To get white color:

- 1. Click on the color button
- 2. Move the last slider to the right to get the color white.
- 3. Click on "OK"


C-MOR Video Surveillance





Paint the area with white color. In the white area motion detection will be active.





This is the final step. The image-mask is ready to be used. You just have to save it.

- 1. Click on "File"
- 2. Click on Save and locate a place where you will find that file. Remember that place. Follow the dialog which opens.

After that you can upload the image mask to C-MOR



3.2.8.3 Insert and apply an image mask

Next, the mask has to be uploaded on C-MOR. Please switch to the camera configuration menu of the camera for which to limit the motion detection. In the example this is "Camera 1". Please select the "System Administration" page on your C-MOR web. Scroll down to "Camera Configuration" and select "Camera 1".

Camera Configuration	(open/close)
Change Configuration Camera 1 Entrance	
Change Configuration Camera 2 Warehouse	
Change Configuration Camera 3 Office	

The menu for the camera management opens now. Scroll down to area "Picture Mask for...":





The just created mask has to be chosen and has to be uploaded. Click on "Select Mask", browse to the place where you saved the image mask. Select the just created mask and click open.

Ø		Choose File to Upload					×
🔄 🏵 🕆 🚹 🕨	'illi Berger → Downloads → Mask			v C	Search Mask		,p
Organise 👻 New fold					8	•	0
a 🔆 Favourites	Name	Date modified	Туре	Size			
E Desktop	livepicture	04/10/2013 12:45	JPG File	32 KI	В		
🚺 Downloads	mask-camera	04/10/2013 13:01	JPG File	8 KI	В		
🔚 Recent places							
E							
▲ □ Libraries							
Documents Music							
P and Music Pictures							
Videos							
🛛 🌉 Computer							
🛛 📬 Network							
					A 11 E 1 (0 40		
File n	ame: mask-camera			¥	All Files (*.*)		~
					Open	Cance	

Click on "load File" after the file has been selected:

Picture Mask for th	e Definition of the	Picture area in which Mo	tion Detection is active
Mask is not available. La Camera is not active. No		ure available.	
Load Mask File:	elect Mask	Load File	
Mask active: no. Motion	detection within the wh	le picture is enabled.	
Activate Mask	Deactivate Mask	Delete Mask	

The file is uploaded to C-MOR. Click now "Activate Mask" to enable the created motion detection mask:



The mask is now activated! Click on *"Camera Configuration*" to assure the mask is active and is defined for the right motion area:



The created mask is shown beside the live picture. To the far right the mask is shown in front of the live viewing.

Picture Mask for the Definition of the Pic	ture area in which Motion Detection is active	
Camera Picture	Mask	Mask on Camera Picture
Motion detection is only enabled for the white area of	the mask. The complete picture is recorded!	
Load Mask File: Select Mask Loa	ad File	
Mask active: yes. Motion detection is enbabled for the	e white area only.	
Activate Mask Deactivate Mask	Delete Mask	
Cam Administration (Settings directly on the IF	Cam)	

If you would like to correct the mask, simply edit the created mask again in Windows Paint or with <u>https://www.pixlr.com/editor/</u> and upload it like you did before.

Important Note:

The black area will also be completely recorded! Just motion will not be recognized. Please refer to your camera manual if you would like to use a privacy mask, a function where the complete area already can be broadcasted blacked out or contact C-MOR directly under <u>www.c-mor.com</u>.

Please note that a mask needs to have the same width and height like the camera image. If the mask has other dimensions, it leads to failure.



3.2.9 The C-MOR PTZ Control

Behind the term PTZ-Control (PTZ: Pan/Tilt/Zoom) stands the Motion of moveable cameras directly with the C-MOR Web Interface.

A great advantage of the PTZ-Control is the consistent interface for all camera types. Also no software has to be installed on the PC to manage the cameras. Furthermore the PTZ control works with the iPhone, iPod or iPad and other mobile devices with internet function.

For the configuration of the PTZ-Cameras there is a configuration page in the C-MOR web interface that can be reached from the camera configuration page.

C-MOR	IP Video Surveilland	Motion Detection is on Email Alarm is on	C-MOR-Stream						
C-PICIN	Start Menu	Quickstart	Recordings	System Administration	System Status	Logout			
and you see more!	Cam 1 Cam 2 C	am 3							
You are in the		Configuration Camera 1							
Cam Configuration Menu									
Configuration Cam Network Data	Cam Location:	Cam Location: Change Location							
Configures the IP Address, TCP Port, user name and password to enable C-MOR to access the cam.	Recording cam 1: deactivated Start Recording								
With the button 'Check IP and Port' you can easily check whether a camera can be reached. This function can only be used with TCP ports. In addition, no camera logins or passwords are checked!	Camera PTZ Configurati	Camera PTZ Configuration							
Cam Type Configuration	upload_backup_cam3_2019	upload_backup_cam3_2019-08-06-12-59-02.cbkf 💲 Load Backup Data Backups							
Select the Camera type that C-MOR records.									
* This camera has not yet been tested by the C-MOR team itself.	itself.								
The configuration parameters are based on information from third parties.	Camera Network Data								
Cam Settings	IP Address/DNS Name	172.20.1.68							
Configures cam recording options.	TCP-IP-Port	554							
Time controlled recordings	User Name	viewer							
Configures "fixed" recording schedule.	Password								
Recording by motion detecting and time	Check IP and Port								

In the PTZ configuration page all known PTZ cameras are available. In the section **Load pre-defined camera data** the settings for the PTZ camera can be loaded.



PTZ Configuration for Camera 1						
PTZ function camera 1: disabled Enable PTZ						
Load pre-defined camera data						
ABUS-SC TVIP21550 PT						
Access data for the camera (needs access to control the camera!)	Camera orientation					
User name	• 0 degrees					
Password	 90 degrees 180 degrees 					
IP/Name	O 270 degrees					
TCP-IP-Port						

Simply select the right camera in drop-down menu.

Load pre-defined camera data			
ABUS-SC TVIP21550 PT	¥	Load camera data	
ABUS-SC TVIP21550 PT ABUS-SC TVIP21551 PT	î		
Allnet 2272 PT Allnet 2282 PT		access to control the camera!)	Camera orientation
Allnet 2297 PTZ			
ALONMA PT Axis 212 PTZ			0 degrees 90 degrees
Axis 215 PTZ Axis P5532 PTZ			O 180 degrees
Axis Q6032 PTZ			O 270 degrees
INTELLINET NSC18-WN INSTAR IN-3010			
JVC VN-V686 LevelOne FCS-0020		ommand	
LevelOne FCS-1010		onmand	
LevelOne WCS-2010 LevelOne FCS-1040/WCS-2040			
LevelOne FCS-6010			
LevelOne WCS-6020 Linksys PVC 300	~		
LINKSYS PVC 300	<u> </u>		

If the PTZ configuration of the selected camera was loaded, the second step follows for the configuration of the PTZ control: The setup of the login data for the camera and the setting for the camera rotation.

ABUS-SC I	/IP21550 PT v Load camera data			
Access dat	a for the camera (needs access to control the camera!)	Camera orientation		
User name	admin	 0 degrees 90 degrees 180 degrees 270 degrees 		
Password	••••			
IP/Name	172.20.1.76			
TCP-IP-Port	80			
PTZ commar	d Camera command			
.eft	/cgi-bin/operator/ptzset?move=left			
Right	/cgi-bin/operator/ptzset?move=right			
Up /cgi-bin/operator/ptzset?move=up				
Down	/cgi-bin/operator/ptzset?move=down	/cgi-bin/operator/ptzset?move=down		
Zoom in	Not supported by camera			

If the camera was fixed on a ceiling, which has the effect, that the camera is upside down, the PTZ control has to be configured with the rotation of 180 degrees. Otherwise the PTZ commands will navigate to the wrong direction.

Of course the loaded PTZ commands can be adjusted. If a camera has a configurable pan or tilt setting, so the command can be adjusted with your own requirements.



Next to the control commands for pan, tilt and zoom, moveable cameras usually own the function to set up pre-defined positions. These positions can be stored in the PTZ menu, too. The pre-defined positions commands you will find in the C-MOR web forum or by asking the C-MOR support team.

PTZ command	Camera command	
Left	/command/ptzf.cgi?Relative=0401	
Right	/command/ptzf.cgi?Relative=0601	
Up	/command/ptzf.cgi?Relative=0801	
Down	/command/ptzf.cgi?Relative=0201	
Zoom in	/command/ptzf.cgi?Relative=1104	
Zoom out	/command/ptzf.cgi?Relative=1004	
Pre-defined Position	Camera command	Name/description
Preset Position 1	/command/presetposition?PresetCall=1	StartPoint
Preset Position 2	/command/presetposition?PresetCall=2	Castle
Preset Position 3	/command/presetposition?PresetCall=3	Church Downtown
Preset Position 4	/command/presetposition?PresetCall=4	Gas Company
Preset Position 5		
Preset Position 6		
Preset Position 7		
Preset Position 8		


If the PTZ commands are configured, at least you have to activate the PTZ control over the camera Menu.

	PTZ Configuration	for Camera 1	
PTZ function	camera 1: disabled Enable PTZ		
Load pre-de	fined camera data		
ABUS-SC T	VIP21550 PT		
Access dat	a for the camera (needs access to control the camera!)	Camera orientation	
User name	admin	• 0 degrees	
Password		○ 90 degrees	
IP/Name	172.20.1.76	 180 degrees 270 degrees 	
TCP-IP-Port	80		



3.2.10 Usage of the PTZ control

If the PTZ function is activated for a camera, the control icons will be shown on the camera web pages automatically.



The PTZ buttons are self-explanatory. These functions are pan from left to right, tilt from up and down and zoom in and out.

In the drop-down menu underneath the pan, tilt and zoom buttons you will find the menu for the pre-defined positions.



4 Legal Information

The software of C-MOR is a bundle consisting of free and commercial software. The free program sections are licensed according to GPL and can be freely used, copied and distributed. By purchasing C-MOR the purchaser obtains a user license for the complete software package but is not allowed to copy it.

4.1 Disclaimer

The software in use with the device is basically a combination of free software, open source, that is licensed by the authors without any occurring cost. As far as not stated explicitly in the license of the individual software packages, the following disclaimer is valid: za-internet GmbH does not assume any liability or warranty for the program as far as it is legally permissible. Unless otherwise confirmed in written form, the copyright owners and/or third parties provide the program "as it is" without any warranty. Neither explicitly, nor implicitly, including –but not limited to - marketability or usability for a particular aim.

The full risk of quality and capability lies with the user. In case the program turns out to be erroneous, the costs for required service, repairing or correction have to be borne by the user.

Neither the copyright owner, nor any third party who has modified and distributed the program as allowed above, is liable for any damages – the use of this program is at your own risk unless there is no valid applicable law or written agreement. This applies for any general or specific damages, damages by side effects or consequential damages that result from the use or uselessness of the program (including – but not limited to – loss of data, erroneous data processing, losses that have either to be covered by you or others or the inability of the program to work together with other programs), even when the copyright owner or a third party was informed of the possibility of such damages.

4.2 Warranty

The distributor where the devices have been purchased (za-internet GmbH or specialized seller), issues a 2-year warranty for material and workmanship for products with undamaged seal of quality from the day of delivery.

In the first instance the purchaser has a right to supplementary performance.

The supplementary performance either provides rectification or delivery of conforming goods. Replaced parts or devices will pass into the property of the seller.

In case supplementary performance cannot be carried out, the purchaser can either claim abatement of the purchaser's price or withdraw from the purchase contract. As far as it is a defect the seller is responsible for, the purchaser can claim compensation or refund of vain expenses

The purchaser has to announce obvious defects immediately.

Verification of warranty claim has to be adduces with proper purchase certificate (sales receipt or invoice).

All damage which has arisen due to improper treatment, operation, storage as well as force majeure or other external influences are excluded under the warranty.

In case of an assumed warranty case, please contact our support during business hours. Please find contact details in the appendix.

5 GNU Public License, GPL

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

5.1 Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

5.2 Terms and Conditions for Copying, Distribution and Modification

§0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

§1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

§2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

1. You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

2. You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

3. If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensee very part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.



§3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

1. Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

2. Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

3. Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

§4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

§5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

§6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

§7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty- free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

§8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

§9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

§10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

§11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

§12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.



6 Appendix - Contact Information

C-MOR by za-internet GmbH

Linsenäcker 13 72379 Hechingen, Germany

Support and Headquarters:

Tel.: +49 74 71 / 93 01 99-40 Fax.: +49 74 71 / 93 01 99-97

Support via web:

http://www.c-mor.com/supportform.php

Information on the Internet:

www.c-mor.com www.c-mor.de

VAT ID: DE812900780, Commercial register: Stuttgart HRB 420820, Management board: Michael Reuschling, Peter Steinhilber